

Cat. No. 43-1102
OWNER'S MANUAL

Please read before using this equipment.

ET-1102

**900 MHz Digital Spread Spectrum
Cordless Telephone
with Caller ID/Call Waiting ID**



RadioShack®

FEATURES

Your RadioShack ET-1102 900 MHz Digital Spread Spectrum Cordless Telephone uses advanced cordless telephone technology to give you superior audio quality and extended range.

The ET-1102's Caller ID unit records each caller's telephone number (and name, if available in your area) and the day and time of the call, as provided by your local phone company to Caller ID service subscribers. And, if you subscribe to Call Waiting with Caller ID, the ET-1102 can show you the incoming caller information, even when you are already on the phone.

Your ET-1102 has these features:

900 MHz Operation — provides longer range and less interference than many other cordless phones.

Spread Spectrum Technology — spreads the signal across several frequencies, providing additional security for your phone conversations.

Caller ID Memory — stores up to 50 Caller ID records.

3-Line Liquid Crystal Display — lets you view an entire Caller ID record on one screen.

10-Number Memory Dialing — lets you store up to 10 numbers in memory for easy dialing.

Volume Control — lets you adjust the volume you hear through the handset.

Adjustable Ringer — lets you choose high or low volume for the ET-1102's ringer.

Page — lets you send a signal from the base to the handset to page someone or to help you locate the handset if you have misplaced it.

Facedown or Faceup Handset Charging — you can place the handset on the base facedown or faceup (to show the Caller ID display, for example).

Wall Mountable — you can mount the ET-1102 on the wall to save space on your desk top.

Ample Talk and Standby Time — the supplied battery (when fully charged) provides about 4 hours of talk time or 7 days of standby time.

20 Channels — automatically selects a clear channel when you make or answer a call.

Security Access-Protection Code — automatically prevents other cordless phone users from using your phone line while the handset is off the base.

Redial — lets you quickly redial the last number dialed.

Flash — sends an electronic switch-hook signal for use with special phone services, such as Call Waiting.

Tone/Pulse Dialing — lets you use either type of service, and you can easily switch from pulse to tone dialing for long-distance, bank-by-phone, or other special services.

Auto Talk — you can set the phone so you can answer a call simply by lifting the handset from the base.

Any Key Answer — you can set the phone so you can press any key to answer a call when the handset is away from the base.

Hearing-Aid Compatibility — lets you use your phone with hearing aids that have a T (telephone) switch.

This telephone has been tested and found to comply with all applicable UL and FCC standards.

We recommend you record your phone's serial number here. The number is on the bottom of the base.

Serial Number _____

Important Caller ID Information

To use the phone's Caller ID and Caller ID with Call Waiting features, you must be in an area where those services are available and you must subscribe to those services through your local phone company.

Where Caller ID is offered, one or more options are generally available:

- caller's number only
- caller's name only
- caller's name and number

Warning: To prevent fire or shock hazard, do not expose this product to rain or moisture.

	CAUTION RISK OF ELECTRIC SHOCK. DO NOT OPEN.	
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.		



This symbol is intended to alert you to the presence of uninsulated dangerous voltage within the product's enclosure that might be of sufficient magnitude to constitute a risk of electric shock. Do not open the product's case.



This symbol is intended to inform you that important operating and maintenance instructions are included in the literature accompanying this product.

Important:

- Cordless phones such as this one require AC power to operate. When the AC power is off, you cannot dial out or receive incoming calls using your ET-1102. To be safe, you should also have a phone that does not need AC power to operate (not a cordless phone) so you can still make and receive calls if there is an AC power failure.
- When AC power is lost, the ET-1102 loses the security access-protection code connection between the base and the handset. When power is restored, put the handset on the base briefly to restore this connection so you can use the handset.

READ THIS BEFORE INSTALLATION

We have designed your phone to conform to federal regulations and you can connect it to most phone lines. However, each device that you connect to the telephone line draws power from the line. We refer to this power draw as the phone's *ringer equivalence number*, or REN. The REN is on the bottom of your phone.

If you use more than one phone or other device on the line, add up all the RENs. If the total is more than five, your phones might not ring. In rural areas, a total REN of three might impair ringer operation. If ringer operation is impaired, remove one of the devices from the line.

FCC STATEMENT

Your telephone complies with Part 68 of *FCC Rules*. You must, upon request, provide the FCC registration number and the REN to your phone company. These numbers are on the bottom of the base.

You must not connect your phone to any of the following:

- coin-operated systems
- party-line systems
- most electronic key phone systems

This equipment complies with the limits for a Class B digital device as specified in Part 15 of *FCC Rules*. These limits provide reasonable protection against radio and TV interference in a residential area. However, your equipment might cause TV or radio interference even when it is operating properly. To eliminate interference, you can try one or more of the following corrective measures.

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the radio or TV.
- Use outlets on different electrical circuits for the equipment and the radio or TV.

Consult your local Radio Shack store if the problem still exists.

CONTENTS

Installation	6
Mounting the Phone	6
On a Desk	6
On a Wall Plate	7
Directly on the Wall	8
Connecting and Charging the Battery Pack	9
Setting the Dialing Mode	11
Setting the Ringer's Volume	12
Using Auto Talk	12
Turning Caller ID/Call Waiting On/Off	12
Storing Your Area Code	13
Telephone Operation	14
Making and Receiving Calls	14
Adjusting the Handset Volume	14
Using REDIAL	14
Using FLASH	15
Using Tone Services on a Pulse Line	15
Paging	15
Memory Dialing	16
Storing a Name and Number in Memory	16
Editing or Deleting a Number in Memory	17
Entering a Pause	18
Reviewing Memory Numbers	18
Dialing a Memory Number	18
Chain-Dialing Service Numbers	19
Testing Stored Emergency Numbers	19
Using a Headset	19
Caller ID Operation	20
Reviewing Caller ID Records	20
Caller ID Messages	21
Dialing Numbers from a Caller ID Record	21
Storing a Caller ID Record to Memory	21
Deleting Caller ID Records	22
Troubleshooting	23
Care and Maintenance	25
Replacing the Battery Pack	26
The FCC Wants You to Know	27
Lightning	27

INSTALLATION

MOUNTING THE PHONE

You can place the ET-1102's base on a desk or table, mount it on a standard wall plate, or mount it directly on a wall. Choose a location that is:

- near an AC outlet
- near a telephone line jack
- out of the way of normal activities
- away from electrical machinery, electrical appliances, metal walls or filing cabinets, wireless intercoms, alarms, and room monitors
- away from other cordless phones

The base's location affects the handset's range. If you have a choice of several locations, try each to see which provides the best performance.

Caution: The supplied RadioShack adapter was designed specifically for your ET-1102. Use only the supplied adapter.


Notes:

- Your telephone connects directly to a modular phone line jack. If your phone line jack is not a modular jack, you can update the wiring yourself, using jacks and adapters available from your local RadioShack store. Or, you can let the telephone company update the wiring for you.
- The USOC number of the jack to be installed is RJ11C, or RJ11W for a wall plate jack.


On a Desk

Follow these steps when you place the base on a desk or table.

1. Insert the bracket's tabs into the base's upper tab slots as shown, then press down on the bracket's clips and insert them into the clip slots.




2. Plug one end of the supplied long modular cord into the **TEL LINE** jack on the back of the base.




3. Plug the modular cord's other end into a modular phone line jack.




4. Insert the supplied AC adapter's barrel plug into the **DC IN 9V** jack on the back of the base.



5. Route the adapter's cord through the strain relief slot on the bracket.




6. Plug the adapter into a standard AC outlet.




7. Lift the base's antenna to a vertical position.

On a Wall Plate


1. Insert the bracket's tabs into the base's lower tab slots as shown, then press down on the bracket's clips and insert them into the clip slots.




2. Plug one end of the supplied short modular cord into the **TEL LINE** jack on the back of the base.




3. Insert the supplied AC adapter's barrel plug into the **DC IN 9V** jack on the back of the base.




4. Route the adapter's cord through the narrow groove on the bottom of the bracket.



5. Plug the modular cord into the wall plate jack, then align the bracket's keyhole slots with the wall plate studs and slide the base downward to secure it.



6. Plug the adapter into a standard AC outlet.



7. Press and lift out the handset holder, rotate it 180°, then snap it back into place.




8. Lift the base's antenna to a vertical position.


Directly on the Wall

For this mounting method, you need two screws (not supplied) with heads that fit into the keyhole slots on the bottom of the base.


1. Drill two holes $3\frac{15}{16}$ inches (100 mm) apart. Then thread a screw into each hole, letting the heads extend about $\frac{5}{16}$ inch (8 mm) from the wall.




2. Insert the bracket's tabs into the base's lower tab slots as shown, then press down on the bracket's clips and insert them into the clip slots.




3. Plug one end of the supplied long modular cord into the **TEL LINE** jack on the back of the base.




4. Insert the supplied AC adapter's barrel plug into the **DC IN 9V** jack on the back of the base.



5. Route the modular and adapter cords through the grooves on the bottom of the bracket.




6. Align the keyhole slots with the mounting screws, and slide the base downward to secure it.



7. Plug the modular cord into a modular phone line jack.

8. Plug the adapter into a standard AC outlet.



9. Press and lift out the handset holder, rotate it 180°, then snap it back into place so it holds the handset.




10. Lift the base's antenna to a vertical position.


CONNECTING AND CHARGING THE BATTERY PACK

The ET-1102 comes with a rechargeable nickel-cadmium battery pack in the handset but not connected. Before using your phone, you must connect the battery pack, then charge it for about 24 hours.

1. Press down and slide off the battery pack compartment cover as shown.




2. Unfasten the plastic retainer strap and lift the battery pack out of the compartment.



3. Plug the battery pack's connector into the socket in the compartment (the connector fits only one way), then replace the battery pack and fasten the retainer strap.

4. Replace the cover.

To charge the battery pack, place the handset either faceup or facedown on the base. The CHARGE indicator on the base lights and **Total:00** appears on the handset display.



Recharge the battery pack when **Low Battery** flashes on the display.


Important: Be sure the battery pack is properly connected before you try to charge it. The CHARGE indicator lights when the handset is on the base, even if the battery pack is not connected.

Notes:

- When you first use the phone after charging or recharging the battery pack, the phone might not work and you might hear an error tone when you press **TALK**. If this happens, return the handset to the base for about 5 seconds. This resets the security access-protection code.
- If the base loses power for 30 minutes while the handset is away from it, the security access-protection code might be lost. To reset the code, return the handset to the base for about 5 seconds.

The handset does not lose its security access-protection code even if the battery pack is completely discharged.

- Using a pencil eraser, clean the charging contacts on the handset and the base about once a month.




- If the battery pack becomes weak during a call, the handset beeps every 3 seconds and **Low Battery** flashes. When this happens, you cannot make another call on the phone until you recharge the battery pack.
- About once a month, fully discharge the battery pack by keeping the handset off the base until **Low Battery** flashes. Otherwise, the battery pack loses its ability to fully recharge.
- If the display is blank and the phone does not work, recharge the battery pack. (The battery power might be too low to light the display.)
- If you are not going to use your phone for an extended period of time, disconnect the battery pack. This increases the battery pack's usable life.
- The supplied battery pack should last for about a year. When it loses its ability to fully recharge, order a replacement battery pack from your local RadioShack store (see "Replacing the Battery Pack" on Page 26).


SETTING THE DIALING MODE

Set **DIAL MODE** on the back of the base for the type of service you have. If you are not sure which type you have, once the battery pack is fully charged, do this test.

1. Be sure **DIAL MODE** is set to **T** (tone).



2. Lift the handset, press **TALK**, and listen for a dial tone.



3. Press any number other than **0**.


Note: If your phone system requires that you dial an access code (9, for example) before you dial an outside number, do not dial the access code either.

If the dial tone stops, you have touch-tone service. Leave **DIAL MODE** set to **T**.


If the dial tone continues, you have pulse service. Set **DIAL MODE** to **P** (pulse).

SETTING THE RINGER'S VOLUME

At any time except during a call, press **VOL s** or **t** to set the ringer volume. The phone rings at the selected volume and the display shows **Ringer High** or **Ringer Low**.



- Press **SELECT** to change the auto talk setting. **On** or **Off** appears indicating the selected setting.




- To clear the display when you finish, press **FUNCTION** or return the handset to the base.

USING AUTO TALK

Your phone is preset so you must press **TALK** to answer a call. With auto talk turned on, you can answer a call by just lifting the handset from the base, or, if the handset is away from the base, by pressing any key.

Follow these steps to turn auto talk on or off.

- Lift the handset and press **FUNCTION**. A menu appears with **Auto Talk** selected.



TURNING CALLER ID/ CALL WAITING ON/OFF

If you have Call Waiting with Caller ID service, you can set the ET-1102 to show Caller ID information for an incoming call even while you are already on the phone.

Follow these steps to turn the Caller ID/ Call Waiting feature on or off.


- Lift the handset and press **FUNCTION**.
- Press **2** or **t** to select **CIDCW** (Caller ID/Call Waiting).
- Press **SELECT** to change the Caller ID/Call Waiting setting. **On** or **Off** appears indicating the selected setting.
- Return the handset to the base to store the new setting.

STORING YOUR AREA CODE

To quickly dial a number from a Caller ID record (see "Dialing Numbers from a Caller ID Record" on Page 21) or to correctly store a number from a record into a memory dialing location (see "Storing a Caller ID Record to Memory" on Page 21), you must store your local area code in the ET-1102's memory. Then, when you dial from a Caller ID record, the ET-1102 skips the area code if it matches the one you stored.

Follow these steps to store your area code.

1. Lift the handset and press **FUNCTION**.
1. Press **3** (or t twice) to select **Area Code**.
2. Press **SELECT**, then enter your 3-digit area code. If you make a mistake, repeatedly press ◀ or ▶ to move the cursor over the incorrect digit, then enter the correct number.
3. Press **SELECT** to store the area code, then press **FUNCTION** or return the handset to the base to clear the display.




Note: If an area code is already stored, it appears on the display when you press **SELECT**. To delete the area code, press **DELETE** three times. Then enter your area code.

TELEPHONE OPERATION

MAKING AND RECEIVING CALLS

To make a call, lift the handset and press **TALK** (the IN USE indicator on the base lights), then dial the number. You see the number as you dial, then (after a few seconds) the call's elapsed time.




Note: You can also dial the number before you press **TALK**. If you make a mistake, repeatedly press ◀ or ▶ until the cursor is over the incorrect digit, then enter the correct number.

To answer a call, lift the handset from the base and press **TALK**. If auto talk is on, just lift the handset from the base, or, if the handset is away from the base, press any key.

To end a call, place the handset on the base or press **TALK**.


ADJUSTING THE HANDSET VOLUME

To adjust the volume of the sound you hear through the handset, during a call, press **VOL t** for normal volume or **VOL s** for high volume. The display shows **Volume Normal** or **Volume High**.



USING REDIAL

You can quickly dial the last number dialed. Lift the handset and press **TALK**, then press **REDIAL**.




Notes:

- You can also press **REDIAL** (so you see the stored number) first, then press **TALK**.
- The redial memory holds up to 32 digits, so you can redial long-distance as well as local numbers.
- The redial memory also holds pause entries. See "Entering a Pause" on Page 18.

USING FLASH

FLASH performs the electronic equivalent of a switchhook operation for special services, such as Call Waiting.



For example, if you have Call Waiting, press **FLASH** to answer an incoming call without disconnecting the current call. Press **FLASH** again to return to the first call.


Note: If you do not have any special phone services, pressing **FLASH** might disconnect the current call.

USING TONE SERVICES ON A PULSE LINE

Some special services, such as bank-by-phone, require tone signals. If you have pulse dialing, you can still use these special tone services by following these steps.

1. Be sure **DIAL MODE** is set to **P**.
2. Dial the service's main number.

3. When the service answers, press **TONE(*)**. Any additional numbers you dial are sent as tone signals.




4. To reset the phone to pulse dialing, simply hang up or press **FLASH** (see "Using FLASH" on Page 15).

PAGING

To page the person who has the handset or to locate the handset when the phone is not in use, press **PAGE/FIND**. The handset beeps for 2 seconds.

To have the handset beep for a full minute, hold down **PAGE/FIND** for 2 seconds. To stop the beeping sooner, press **TALK** twice.



MEMORY DIALING

You can store up to ten phone numbers and names in memory, then dial a stored number by entering its memory location number.


Each stored number can be up to 20 digits, and each name can be up to 14 characters.

Storing a Name and Number in Memory

Notes:


- An error tone sounds and the phone exits the storing process if you wait more than 20 seconds between each key press.
- If you receive a call during memory entry, the phone exits the storing process.

1. Lift the handset.
2. Hold down **MEM** until **Memory Store** and a list of memory location numbers appears.




3. Choose a memory location (0–9) by pressing a number or by repeatedly pressing s or t.

4. To store a name, press **SELECT**. **Store Name** appears.



If you do not want to enter a name, skip to Step 6. **<Memory n>** will be stored as the name (*n* is the location number you selected).

5. To enter a name, use t or s to select the characters and ◀ or ▶ to move the cursor.




Repeatedly press t to see the characters in alphabetical order. (The display shows uppercase letters first, then lowercase letters, numbers, and special characters.)

Notes:

- Press s to see the characters in reverse alphabetical order.
- You can hold down s or t to scroll rapidly through the characters.

- If you make a mistake, move the cursor over the error, then enter the correct character, or press **DELETE** to delete a character. To delete all the characters, hold down **DELETE** for at least 1 second.




6. Press **SELECT**. **Store Number** appears.
7. Enter the phone number and any tone or pause entries (see "Using Tone Services on a Pulse Line" on Page 15 and "Entering a Pause" on Page 18).

Instead of using the lower keypad keys, you can use **t** or **s** to enter the number and other entries and **◀** or **▶** to move the cursor. Repeatedly press **t** to see the numbers first, then special characters, including hyphens, pause entries (**P**), and tone entries (*). Press **s** to see them in reverse order.

8. Press **SELECT**. The phone beeps and **Memory n Stored** appears. After 2 seconds, **Memory Store** appears, and you can repeat Steps 3–8 to store more numbers.
9. When you finish, press **MEM** to exit the **Memory Store** display.

For each stored number, write the person's or company's name next to the appropriate location number on the supplied memory directory sticker. (Use a pencil in case you need to change the number later.) Peel the backing from the sticker and attach it to the phone as shown.



To replace a stored number, simply store a new one in its place.

Editing or Deleting a Number in Memory

Follow these steps to edit or delete a memory number.

1. Lift the handset.
2. Hold down **MEM** until **Memory Store** and a list of memory location numbers appear on the display.
3. Choose a memory location (0–9) by pressing a number or by repeatedly pressing **s** or **t**.

4. Press **SELECT**. A menu appears with the three options listed below. Press **s** or **t** to choose an option, follow the instructions listed, then press **SELECT**.


Edit Memory *n*. Edit the record as described in Steps 5 through 8 of "Storing a Name and Number in Memory" on Page 16.

Delete Memory *n*. The display prompts you to confirm the deletion. Move the cursor to **Yes** or **No**, then press **SELECT** or **DELETE**. The phone beeps, and **Memory *n* Deleted** appears.

Go Back. Returns you to the list of memory numbers.

Entering a Pause

In some telephone systems, you must dial an access code (9, for example) and wait for a second dial tone before you can dial an outside number. You can store the access code with the phone number. However, you should also store a pause after the access code to allow the outside line time to connect. To enter a 2-second pause, press **PAUSE** or use **s** or **t** to select **P** on the display. You can add more pause entries for a longer pause.



Reviewing Memory Numbers

To review your memory numbers, press **MEM**. The list of memory location numbers (0–9) appears with the name stored with each number (or **<Memory *n*>** if you did not store a name).

To see the stored phone numbers, press **►**. An arrow to the right of the number means it is longer than 14 digits. Press **►** again to see the rest of the number. Repeatedly press **◀** to return to the name display.

To exit the memory number list, press **MEM**.

To see a stored name and phone number at the same time, press **SELECT** when the cursor is by a memory location number. To exit this display without storing any changes, hold down **DELETE** until the display clears.

Dialing a Memory Number

To dial a number stored in memory, lift the handset and press **MEM**. The list of memory location numbers appears. Choose a memory location (0–9) by pressing a number or by repeatedly pressing **s** or **t**, then press **TALK**.

You can also dial a memory number by pressing **TALK** first, then pressing **MEM** and entering a memory location number.

Chain-Dialing Service Numbers

For quick recall of numbers for special services (such as bank by phone), store each group of numbers in its own memory location.

Dial the service's main number first. Then, at the appropriate place in the call, press **MEM** and enter the number for the location where the additional information is stored.


Testing Stored Emergency Numbers

If you store an emergency service's number (police department, fire department, ambulance) and you choose to test the stored number, make the test call during the late evening or early morning hours to avoid peak demand periods. Also, remain on the line to explain the reason for your call.

USING A HEADSET

You can make or answer calls with hands-free convenience using an optional headset that has a $\frac{3}{32}$ -inch (2.5-mm) plug. Contact your local RadioShack store for a suitable headset.

To connect the headset, pull open the rubber cover marked  on the side of the handset, then insert the headset's plug into the jack.



Notes:

- Connecting a headset disconnects the handset's earpiece and microphone.
- **VOL** s or t on the handset also controls the headset's volume.
- If you place the handset on the base to recharge it while the headset is connected, be sure the handset seats properly.

With a headset connected, you can make or answer calls as usual using the keys on the handset.

You can use a handset holder (available from your local RadioShack store) to hang the handset on your belt for greater convenience.

When you finish using the headset, disconnect it from the handset and close the rubber cover to protect the jack.

CALLER ID OPERATION

If you subscribe to Caller ID service from your phone company, the phone company sends information about the call, as well as the time and date, between the first and second rings of every call you receive.

The ET-1102 displays this information when it receives a call, and it stores up to 50 Caller ID records for later review. It also shows if caller information is unavailable or if the name and number were blocked by the caller (see "Caller ID Messages" on Page 21).

If you subscribe to Call Waiting with Caller ID, you will hear a tone through the handset when a call comes in, then the Caller ID record appears. If you want to answer the incoming call, press **FLASH**. To resume the previous phone conversation, press **FLASH** again.


If the ET-1102's Caller ID memory becomes full, any new call replaces the oldest call's record.

Note: If the handset is faceup on the base, it shows the number of Caller ID records, so you can see if you have new records to review.

Repeatedly press **t** to scroll through the Caller ID records from the newest to the oldest, or **s** to scroll back through the records. To scroll quickly through the records, hold down **t** or **s**.


When you scroll past the last record, **End** appears. When you scroll past the first record, the record totals appear.

The top line of each record shows the date, time and the number of calls from that number. The second line shows the caller's name, and the third line shows the caller's phone number.



REVIEWING CALLER ID RECORDS

To review the Caller ID records, lift the handset and press **CALL ID**. The number of new Caller ID records, if any, and the total number of records appears.



Caller ID Messages

Display	Description
New :XX Total:XX	Shows the number of new Caller ID records (records you have not reviewed) and the total number of records.
Private Name or Private Number	The caller has blocked the Caller ID information from being sent.
Unknown Name or Unknown Number	The caller is not within a Caller ID service area.
Error	Appears if there was an error during the transmission of Caller ID information. Minor electrical disturbances can affect Caller ID information. Occasional errors are normal. If the phone frequently displays Error , contact your local telephone company or RadioShack store for assistance.
End	Appears when you scroll past the oldest Caller ID record.

DIALING NUMBERS FROM A CALLER ID RECORD


To dial a local number stored in a Caller ID record, recall the record, then press **TALK**. If it is a long distance call, press **1** (**1** appears before the displayed number) before you press **TALK**.

Note: If a Caller ID record does not contain a phone number (if it was blocked by the caller, for example) you cannot dial from that record.


STORING A CALLER ID RECORD TO MEMORY

Follow these steps to store the name and number from a Caller ID record into a memory location.

1. Recall the record you want to store, then press **MEM**. **Select Location** appears.



2. Choose a memory location (0–9) by pressing a number or by repeatedly pressing s or t, then press **SELECT**.




If the selected location is empty, the phone beeps to confirm that it stored the number, then the Caller ID record appears.

If a record exists in the selected location, **Replace Memory?** appears, prompting you to confirm the replacement. Move the cursor to **Yes** or **No**, then press **SELECT**.

DELETING CALLER ID RECORDS

You can delete Caller ID records individually or all at once.

To delete a single record, recall it, then press **DELETE**. **Delete Message?** appears, prompting you to confirm the deletion. Move the cursor to **Yes** or **No**, then press **SELECT** or **DELETE**.



To delete all the records at once, recall any record, then hold down s until the record totals appear, then press **DELETE**. **Delete All?** appears, prompting you to confirm the deletion. Move the cursor to **Yes** or **No**, then press **SELECT** or **DELETE**.

TROUBLESHOOTING

We do not expect you to have any problems with your phone, but if you do, the following suggestions might help.

Problem	Suggestion
The phone does not work or works poorly.	Be sure the base's phone line cord and AC adapter are correctly and securely connected.
	Be sure the battery pack in the handset is connected and charged.
	Return the handset to the base for a few seconds to reset the security access-protection code.
The display flashes slowly when the handset is faceup on the base.	Be sure the battery pack in the handset is properly connected.
The handset stops working or works poorly during a call.	Move the handset closer to the base.
	Lift the base's antenna to a fully vertical position.
	Be sure the handset's battery pack is charged. (If the battery pack power is too low, it does not have enough power to light the Low Battery indication on the display.)
Low volume or unusual sounds.	Someone has picked up another phone on the same line. Hang up the other phone.
Severe noise interference.	Keep the handset away from computers, remote control toys, wireless microphones, alarm systems, intercoms, room monitors, fluorescent lights, and electrical appliances.
	Move to another location or turn off the source of interference.
	Hang up and redial the number.

Problem	Suggestion
The phone cannot be operated at a useful distance from the base because the signal becomes weak or noisy (handset's range has decreased).	Lift the base's antenna to a fully vertical position.
	Be sure neither the handset's nor base's antenna is touching a metal surface.
	Recharge the battery pack.
The handset battery pack does not charge.	Check the charging contacts on the handset and base. If they are dirty, clean them with a pencil eraser.
	Be sure the battery pack is properly connected.
	Be sure the handset is properly seated on the base.
	Replace the battery pack (see "Replacing the Battery Pack" on Page 26).
Handset does not ring or receive a page.	Lift the base's antenna to a fully vertical position.
	Move the handset closer to the base.
	Move the base away from other electrical devices.
	Recharge the battery pack.
You have an incoming call, but do not receive any Caller ID information.	Let the phone ring twice before you answer so the system has time to record the Caller ID information.
	Check that the system is correctly and securely connected.
	Call your phone company to verify that your Caller ID service is active.

If you still have problems, disconnect the phone. If other phones on the same line work properly, the fault is in this phone or its installation. If you cannot find the problem, take your ET-1102 to your local RadioShack store for assistance.

CARE AND MAINTENANCE

Your RadioShack ET-1102 900 MHz Digital Spread Spectrum Cordless Telephone is an example of superior design and craftsmanship. The following suggestions will help you care for your ET-1102 so you can enjoy it for years.



Keep the ET-1102 dry. If it gets wet, wipe it dry immediately. Liquids might contain minerals that can corrode the electronic circuits.



Use and store the ET-1102 only in normal temperature environments. Temperature extremes can shorten the life of electronic devices, damage battery packs, and distort or melt plastic parts.



Keep the ET-1102 away from dust and dirt, which can cause premature wear of parts.



Handle the ET-1102 gently and carefully. Dropping it can damage circuit boards and cases and can cause the ET-1102 to work improperly.



Use only a battery pack of the required size and recommended type. Batteries can leak chemicals that damage your ET-1102's electronic parts.



Wipe the ET-1102 with a damp cloth occasionally to keep it looking new. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the ET-1102.


Modifying or tampering with the ET-1102's internal components can cause a malfunction and might invalidate its warranty and void your FCC authorization to operate it. If your ET-1102 is not performing as it should, take it to your local RadioShack store for assistance. If the trouble is affecting the telephone lines, the phone company can ask you to disconnect your ET-1102 until you have resolved the problem.

REPLACING THE BATTERY PACK


If you follow the instructions in "Connecting and Charging the Battery Pack" on Page 9, the battery pack should last about one year. If the battery pack does not hold a charge for more than 2 hours after an overnight charge, replace it with a new 3.6-volt, 600 mAh battery pack with a connector that fits the socket in the battery compartment. You can order a replacement battery pack through your local RadioShack store.

Install the new battery pack as described below, then charge it for about 24 hours.

1. Press down and slide off the battery pack compartment cover as shown.



2. Unfasten the plastic retainer strap and lift the battery pack out of the compartment, then gently pull on the battery connector to disconnect it.
3. Insert the new battery pack's connector into the socket in the compartment, place the battery pack into the compartment, and refasten the retainer strap.



4. Replace the cover.

Cautions:

- You must use a replacement battery pack of the same size and type.
- Do not dispose of the battery pack in a fire because it might explode.
- Do not open or mutilate the battery pack.
- Be careful not to short the battery pack by touching the connector's pins with conducting materials, such as rings, bracelets, and keys. The battery pack or conductor might overheat and burn.

If you have trouble replacing the battery pack, take the phone to your local RadioShack store for assistance.

Important: This product contains a rechargeable nickel-cadmium battery pack. At the end of the battery pack's useful life, it must be recycled or disposed of properly. Contact your local, county, or state hazardous waste management authorities for information on recycling or disposal programs in your area. Some options that might be available are: municipal curb-side collection, drop-off boxes at retailers such as your local RadioShack store, recycling collection centers, and mail-back programs.

THE FCC WANTS YOU TO KNOW

In the unlikely event that your phone causes problems on the phone line, the phone company can temporarily discontinue your service. If this happens, the phone company attempts to notify you in advance. If advance notice is not practical, the phone company notifies you as soon as possible and advises you of your right to file a complaint with the FCC.

Also, the phone company can make changes to its lines, equipment, operations, or procedures that could affect the operation of this telephone. The telephone company notifies you of these changes in advance, so you can take the necessary steps to prevent interruption of your telephone service.

Your phone might cause TV or radio interference even when it is operating properly. To determine whether your phone is causing the interference, turn off your phone. If the interference goes away, your phone is causing it. Try to eliminate the interference by:

- moving your phone away from the receiver
- connecting your phone to an AC outlet that is on a different electrical circuit from the receiver
- contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using your phone.

Some cordless telephones operate on frequencies that might cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR.

LIGHTNING

Your telephone has built-in lightning protection to reduce the risk of damage from surges in telephone line and power line current. This lightning protection meets or exceeds FCC requirements. However, lightning striking the telephone or power lines can damage your telephone.

Lightning damage is not common. Nevertheless, if you live in an area that has severe electrical storms, we suggest that you unplug your phone during storms to reduce the possibility of damage.

Limited One-Year Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for one (1) year from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the limitations on how long an implied warranty lasts or the exclusion of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, Dept. W, 100 Throckmorton St., Suite 600, Fort Worth, TX 76102

We Service What We Sell

3/97

RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

9A8

UCZZ016058Z
 Printed in the Philippines