




# AV-D58

# EZ



# SERVICE MANUAL

STEREO RECEIVER


- This Service Manual contains information about the difference between AV-D58(EZSM,EZNHM) and AV-D58(EZBM). If requiring the other information, see Service Manual of AV-D58(EZ),(S/M Code No. 09-016-444-0R2).
- This Service Manual is for AV-D58(EZSM) Silver color / AV-D58(EZNHM) Champagne Gold color.

# aiwa

S/M Code No. 09-01A-444-0S1


SUPPLEMENT  
DATA














SCHEMATIC DIAGRAM – 3 (FRONT)



## WIRING – 3 (TUNER)













SCHEMATIC DIAGRAM – 5 (HP / VIDEO / VOLUME / SPEAKER)




|  |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |   |   |   |   |   |   |   |   |  |
|--|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|--|
|  | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 |  |
|--|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|--|

DIGITAL C.B



SCHEMATIC DIAGRAM-6 (DIGITAL)






# WIRING – 6 (AMP)

| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|
|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|


H

AMP C.B




TO MAIN C.B CN202

|   |
|---|
| A |
| B |
| C |
| D |
| E |
| F |
| G |
| H |
| I |
| J |
| K |
| L |
| M |
| N |
| O |
| P |
| Q |
| R |
| S |
| T |
| U |



|  |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |   |   |   |   |   |   |   |   |  |
|--|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|--|
|  | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 |  |
|--|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|--|



SCHEMATIC DIAGRAM – 8 (PT / AC OUTLET)

