

4-Bank×2,097,152-Word×16-Bit SYNCHRONOUS DYNAMIC RAM

DESCRIPTION

The MD56V72161C-xxTAP is a 4-Bank \times 2,097,152-word \times 16-bit Synchronous dynamic RAM. The device operates at 3.3V. The inputs and outputs are LVTTL compatible.

FEATURES

Product Name	MD56V72161C-xxTAP xx indicates speed rank.			
Organization	4Bank x 2,097,152Word x 16Bit			
Address Size	4,096Row x 512Column			
Power Supply VCC (Core)	3.3V±0.3V			
Power Supply VCCQ (I/O)	3.3V±0.3V			
Interface	LVTTL compatible			
Operating Frequency	Max. 166MHz (Speed Rank 6)			
Operating Temperature	-40 to +85°C			
Function	Standard SDRAM command interface			
/CAS Latency	2, 3			
Burst Length	1, 2, 4, 8, Full page			
Burst Type	Sequential, Interleave			
Write Mode	Burst, Single			
Refresh	Auto-Refresh, 4,096cycle/64ms, Self-Refresh			
Package	54 pin 400 mil Plastic TSOP(II)			
(Package code)	Cu Frame, Halogen-Free, Pb-Free			
	(P-TSOP(2)54-400-0.80-ZK6)			

PRODUCT FAMILY

VCC Speed		Family	Max.	Access Time (Max.)			
rank	i anniy	Frequency	tAC2	tAC3			
	-6	MD56V72161C-6TAP	166MHz	5.4ns	5.4ns		
3.0V to 3.6V	-7	MD56V72161C-7TAP	143MHz	5.4ns	5.4ns		
3.00 10 3.00	-75	MD56V72161C-75TAP	133MHz	5.4ns	5.4ns		
	-10	MD56V72161C-10TAP	100MHz	6ns	6ns		



MD56V72161C-xxTAP

54 VSS

53 DQ15 52 VSSQ

51 DQ14

50 DQ13

49 VCCQ

48 DQ12 47 DQ11

46 VSSQ

45 DQ10 44 DQ9

43 VCCQ

42 DQ8 41 VSS

40 NC

39 UDQM

38 CLK

37 CKE

36 NC

35 A11 34 A9

33 A8

32 A7 31 A6

30 A5

29 A4

28 VSS

\oslash VCC 1 DQ0 2 VCCQ 3 DQ14 DQ2 5 VSSQ 6 DQ3 7 DQ4 8 VCCQ 9 DQ5 10 DQ6 11 VSSQ 12 DQ7 13 VCC 14 LDQM 15 /WE 16 /CAS 17

/RAS 18

/CS 19 A13 20

A12 21

A10 22 A0 23

A1 24

A2 25

A3 26

VCC 27

PIN CONFIGURATION (TOP VIEW)

54-Pin Plastic TSOP(II)
(K Type)

Pin Name	Function	Pin Name	Function
CLK	System Clock	UDQM, LDQM	Data Input / Output Mask
/CS	Chip Select	DQi	Data Input / Output
CKE	Clock Enable	VCC	Power Supply (3.3V)
A0 to A11	Address	VSS	Ground (0V)
A12,A13	Bank Select Address	VCCQ	Data Output Power Supply (3.3V)
/RAS	Row Address Strobe	VSSQ	Data Output Ground (0V)
/CAS	Column Address Strobe	NC	No Connection
/WE	Write Enable		

Note: The same power supply voltage must be provided to every VCC pin .

The same power supply voltage must be provided to every VCCQ pin.

The same GND voltage level must be provided to every VSS pin and VSSQ pin.

MD56V72161C-xxTAP

PIN DESCRIPTION

Name	Function
CLK	Clock (Input) Fetches all inputs at the "H" edge.
CKE	Clock Enable (Input) Masks system clock to deactivate the subsequent CLK operation. If CKE is deactivated, system clock will be masked so that the subsequent CLK operation is deactivated. CKE should be asserted at least one cycle prior to a new command.
/CS	Chip Select (Input) Disables or enables device operation by asserting or deactivating all inputs except CLK, CKE and UDQM, LDQM.
/RAS	Row Address Strobe (Input) Functionality depends on the combination with other signals. For detail, see the function truth table.
/CAS	Column Address Strobe (Input) Functionality depends on the combination with other signals. For detail, see the function truth table.
/WE	Write Enable (Input) Functionality depends on the combination with other signals. For detail, see the function truth table.
A12,A13 (BA1,BA0)	Bank Address (Input) Slects bank to be activated during row address latch time and selects bank for precharge and read/write during column address latch time.
A0 to A11	Row & column multiplexed. (Input)Row address: RA0 - RA11Column Address: CA0 - CA8
DQ0 to DQ15	3-state Data Bus (Input/Output)
UDQM, LDQM	DQ Mask (Input) Masks the read data of two clocks later when DQM are set "H" at the "H" edge of the clock signal. Masks the write data of the same clock when DQM are set "H" at the "H" edge of the clock signal. UDQM controls DQ15 to DQ8, LDQM controls DQ7 to DQ0.
VCC, VSS	Power Supply (Core), Ground (Core) The same power supply voltage must be provided to every VCC pin. The same GND voltage level must be provided to every VSS pin.
VCCQ, VSSQ	Power Supply (I/O), Ground (I/O) The same power supply voltage must be provided to every VCCQ pin. The same GND voltage level must be provided to every VSSQ pin.
NC	No Connection

MD56V72161C-xxTAP

ELECTRICAL CHARACTERISTICS

Absolute Maximum Ratings

Parameter	Symbol	Value	Unit
Voltage on Input/Output Pin Relative to VSS	VIN, VOUT	–0.5 to Vcc+0.5	V
VCC Supply Voltage	VCC	-0.5 to 4.6	V
VCCQ Supply Voltage	VCCQ	–0.5 to 4.6	V
Power Dissipation (Ta=25°C)	PD	1000	mW
Short Circuit Output Current	IOS	50	mA
Storage Temperature	Tstg	–55 to 150	°C
Operating Temperature	Та	-40 to 85	°C

Notes: 1. Permanent device damage may occur if Absolute Maximum Ratings are exceeded.

2. Functional operation should be restricted to recommended operating condition.

3. Exposure to higher than recommended voltage for extended periods of time could affect device reliability.

4. The voltages are referenced to VSS.

Recommended Operating Conditions (1/2)

Ta= -40 to 85°C Parameter Symbol Min. Тур. Max. Unit Note VCC V Power Supply Voltage (Core) 3.0 3.3 3.6 1,2 Power Supply Voltage (I/O) VCCQ 3.0 3.3 3.6 V 1,2 VSS, VSSQ 0 0 0 V Ground

Notes: 1. The voltages are referenced to VSS.

2. The power supply voltages should input stable voltage. The power supply voltages should not input oscillated voltage. If voltages are oscillating, please insert capacitor near the power supply pins and stop oscillation of voltage.

Recommended Operating Conditions (2/2)

for the second sec	Ta= -4	40 to 85°C			
Parameter	Symbol	Min.	Max.	Unit	Note
Input High Voltage	VIH	2.0	VCC + 0.3	V	1, 2
Input Low Voltage	VIL	-0.3	0.8	V	1, 3

Notes: 1. The voltages are referenced to VSS.

2. The maximum input voltage is as follows, depending on transient pulse width of VCC level. transient pulse width of VCC level < 10nsec VIH(max) = 4.6V

10nsec < transient pulse width of VCC level \leq 20nsec VIH(max) = VCC + 0.5V

3. The minimum input voltage is as follows, depending on transient pulse width of VSS level.

transient pulse width of VSS level < 10 nsec VIL(min) = -1.5V

10nsec < transient pulse width of VSS level ≤ 20 nsec VIL(min) = -0.5V

FEDD56V72161CTAPX-01

MD56V72161C-xxTAP

Pin Capacitance

Ta = 25°C, VCC=VCCQ=3.3V, f=1MHz

Parameter	Symbol	Min.	Max.	Unit
Input Capacitance (CLK)	CCLK	_	4	pF
Input Capacitance (A0 to A13, /RAS, /CAS, /WE, /CS, CKE, UDQM, LDQM)	CIN		5	pF
Input/Output Capacitance (DQ0 to DQ15)	COUT		6.5	pF

DC Characteristics (Input/Output)

Ta= -40 to 85°C VCC = VCCQ = 3.3V±0.3V

100 1000 0.0										
Parameter	Symbol	Condition	Min.	Max.	Unit					
Output High Voltage	VOH	IOH = -2mA	2.4	—	V					
Output Low Voltage	VOL	IOL = 2mA	—	0.4	V					
Input Leakage Current	ILI	0V≦VIN≦VCCQ	-10	10	μA					
Output Leakage Current	ILO	—	-10	10	μA					
NT - TTI 1. 0		LIGG								

Note : The voltages are referenced to VSS.

FEDD56V72161CTAPX-01

MD56V72161C-xxTAP

DC Characteristics (Power Supply Current)

Ta= -40 to $85^{\circ}C$ $VCC = VCCQ = 3.3V \pm 0.3V$

			Condition			MD56V72161C-xxTAP				
Parameter	Symbol		Condition		-6	-7	-75	-10	Unit	Note
		Bank	CKE	Others	Max	Max.	Max.	Max.		
Average Power Supply Current (Operating)	ICC1	One Bank Active	CKE≧VIH	tCC = Min. tRC = Min. No Burst	100	90	85	70	mA	1, 2
Power Supply Current (Standby)	ICC2	All Banks Precharge	CKE ≧ VIH	t _{CC} = Min.	35	35	35	30	mA	3
Average Power Supply Current (Clock Suspension)	ICC3S	All Banks Active	CKE ≦ VIL	t _{CC} = Min.	10	10	10	10	mA	2
Average Power Supply Current (Active Standby)	ICC3	One Bank Active	CKE ≧ VIH	t _{CC} = Min.	50	47	45	45	mA	3
Power Supply Current (Burst)	ICC4	All Banks Active	CKE [≧] VIH	t _{CC} = Min.	130	120	115	100	mA	1, 2
Power Supply Current (Auto-Refresh)	ICC5	All Bank Active	CKE ≧ VIH	t _{CC} = Min. t _{RC} = Min.	135	125	120	110	mA	2
Average Power Supply Current (Self-Refresh)	ICC6	All Banks Precharge	CKE ≦ VIL	t _{CC} = Min.	4	4	4	4	mA	
Average Power Supply Current (Power Down)	ICC7	All Banks Precharge	CKE ≦ VIL	t _{CC} = Min.	3	3	3	3	mA	

Notes: 1. Measured with outputs open.
2. The address and data can be changed once or left unchanged during one cycle.
3. The address and data can be changed once or left unchanged during two cycles.

FEDD56V72161CTAPX-01

MD56V72161C-xxTAP

AC Characteristics (1/2)

Ta= -40 to 85°C VCC = VCCQ = 3.3V±0.3V Note1,2

												te1,2
			MD56V72161C-xxTAP									
Parameter		Symbol	-6		-7		-75		-10		Unit	Note
			Min.	Max.	Min.	Max.	Min.	Max.	Min.	Max.		
Clock Cycle	CL=3	t _{CC3}	6	—	7	—	7.5	—	10		ns	
Time	CL=2	t _{CC2}	10		10		10		10		ns	
Access	CL=3	t _{AC3}		5.4		5.4		5.4	—	6	ns	3,4
Time from Clock	CL=2	t _{AC2}	—	5.4		5.4		5.4	—	6	ns	3,4
Clock High F	Pulse Time	t _{CH}	2	—	2	—	2.5	_	3	—	ns	4
Clock Low F	Pulse Time	t _{CL}	2		2		2.5		3	_	ns	4
Input Set	up Time	t _{SI}	1.5		1.5		1.5		2	_	ns	
Input Hol	ld Time	t _{HI}	0.8		0.8	—	0.8		1	_	ns	
Output Low I Time from		t _{OLZ}	2	_	2	_	2	_	2	_	ns	
Output High Time fror		^t онz	_	5.4	_	5.4	_	5.4	_	6	ns	
Output Hold	from Clock	^t он	2	_	2		2.5	_	2.5	_	ns	3
Random Write Cyc		t _{RC}	60		60		65		70	_	ns	
/RAS Prech	arge Time	t _{RP}	18	_	18		18		20	_	ns	
/RAS Puls	se Width	t _{RAS}	42	10 ⁵	42	10 ⁵	45	10 ⁵	50	10 ⁵	ns	
/RAS to /C/ Tim	•	^t RCD	18	_	18	_	18		20	_	ns	
Write Reco		two	2		2		2		2		Cycle	- 6
		twR	12	—	14	—	15	—	20	_	ns	0
/RAS to /R Active Del		t _{RRD}	10		10		15		20		ns	
Refresh	Time	t _{REF}	_	64		64	_	64		64	ms	5
Power-down Tim		t _{PDE}	t _{SI} +1C LK	_	t _{SI} +1C LK	_	t _{SI} +1 CLK		tSI+1 CLK	_	ns	
Refresh cy	cle Time	t _{RCA}	60		60		65		70		ns	

FEDD56V72161CTAPX-01

MD56V72161C-xxTAP

AC Characteristics (2/2)


Ta= -40 to 85°C VCC = VCCQ = 3.3V±0.3V Note1,2

							NOLE 1,2
Deremeter	Sumbol		MD56V721	1.1	Nata		
Parameter	Symbol	-6	-7	-75	-10	Unit	Note
/CAS to /CAS Delay Time (Min.)	ICCD	1	1	1	1	Cycle	
Clock Disable Time from CKE	ICKE	1	1	1	1	Cycle	
Data Output High Impedance Time from UDQM, LDQM	I _{DOZ}	2	2	2	2	Cycle	
Dada Input Mask Time from UDQM, LDQM	IDOD	0	0	0	0	Cycle	
Data Input Delay Time from Write Command	IDWD	0	0	0	0	Cycle	
Data Output High Impedance Time from Precharge Command	IROH	CL	CL	CL	CL	Cycle	
Active Command Input Time from Mode Register Set Command Input (Min.)	I _{MRD}	2	2	2	2	Cycle	
Write Command Input Time from Output	IOWD	2	2	2	2	Cycle	

Notes: 1. AC measurements assume that tT = 1ns,.

2. Test condition

Parameter	Test Condition		Unit
Input voltage for AC measurement	2.4	V	
Transition Time for AC measurement	tT=1		ns
Reference level for timing of input signal (tT≤1ns)	1.4		V
Reference level for timing of input signal (tT>1ns)	VIH Min. VIL Max.		V
Reference level for timing of output signal	1.4		V



- 4. If tT is longer than 1ns, then the reference level for timing of input signals is VIH and VIL.
- 5. It is necessary to operate auto-refresh 4096 cycles within tREF.
- 6. t_{WR} can be used at one cycle when the clock cycle (t_{CC}) is more than t_{CC} Min. x two cycles.

POWER ON AND INITIALIZE

Be sure to do the following initialization sequence to initialize the inside of the memory after the power supply was turned on and to set up the mode.

Power on Sequence

- (1) Turn on the power after you make input a state of NOP, and input a system clock.
- (2) Take a pose of 200µs and more with making input a state of NOP after VCC and VCCQ reach it in the regular condition.
- (3) Issue the row precharge all bank command (PALL), and secure the row precharge time (tRP).
- (4) Issue the standard Mode Register Set command (MRS), and secure the mode register set command delay time (l_{MRD}).
- (5). Issue the Extended Mode Register set command (EMRS), and secure the mode register set command delay time (l_{MRD}).
- (6) Issue 2 or more auto-refresh commands (REF), and Secure the refresh cycle time (tRCA).

Note:

- 1. (4), (5) or (6): in no special order.
- 2. (5) can be omitted. When it is omitted, it becomes default settings.
- 3. Carry out an initialization sequence after each input terminal reaches a regulation voltage when other input terminals were the undefined setup input (High-Z) at the CKE= "H" time. And, the undefined setup input period of the CKE= "H" time can't hold data. It becomes more effective than writing data after the initialization sequence.

Mode Register Set Command (MRS)

MRS

The mode register stores the data for controlling the various operating modes. It programs the /CAS latency, burst type, burst length and write mode. The default value of the mode register is not defined, therefore the mode register must be written after power up to operate the SDRAM. The mode register is written by mode register set command MRS. The state of address pins A0 to A13 in the same cycle as MRS is the data written in the mode register. Refer to the table for specific codes for various /CAS latencies, burst type, burst length and write mode.

MRS					
CLK	<u>n-1</u>	-n			
CKE	Н	Х			
/CS		L			
/RAS	Х	L			
/CAS	(Idle)	L			
/WE		L			
BA1(A12)	Х	0			
BA0(A13)	Х	0			
A0 to A11	Х	v			

V: The value of mode register set

Extended Mode Register Set Command (EMRS)

The extended mode register stores the data for controlling output driver strength. The default value of the extended mode register is defined. Therefore the mode register must be written after power up to operate the SDRAM. The extended mode register is written by extended mode register set command EMRS. The EMRS register input control is same as MRS settings except for inputting "1" to A12.

If an extended mode register isn't set up, output drivability is full power as default settings. Refer to the table for specific codes for various self-Refresh operations.

<u>EMRS</u>

CLK		l∎] n
CKE	Н	Х
/CS		L
/RAS	Х	L
/CAS	(Idle)	L
/WE		L
BA1(A12)	Х	1
BA0(A13)	Х	0
A0 to A11	Х	v

V: The value of extended mode register set

Wri	te Burst Mode		/CA	S La	tency	E	Burst Type			В	urst Length	
A9	WM	A6	A5	A4	CL	A3	BT	A2	A1	A0	BT = 0	BT = 1
0	Burst	0	0	0	Reserved	0	Sequential	0	0	0	1	1
1	Single	0	0	1	Reserved	1	Interleave	0	0	1	2	2
		0	1	0	2			0	1	0	4	4
		0	1	1	3			0	1	1	8	8
		1	0	0	Reserved			1	0	0	Reserved	Reserved
		1	0	1	Reserved			1	0	1	Reserved	Reserved
		1	1	0	Reserved			1	1	0	Reserved	Reserved
		1	1	1	Reserved			1	1	1	Full Page	Reserved

Mode Register Field Table To Program Mode

Notes: 1. Objects are all family products.

2 A13 and A12 should stay "0" during mode set cycle.

3. A7, A8, A10 and A11 should stay "0" during mode set cycle.

4. Don't set address keys of "Reserved".

Extended Mode Register Set Address Keys

Output Driver Strength					
A6	A5	DS			
0	0	Full (Default)			
0	1	1/2			
1	0	1/4			
1	1	1/8			


Notes: 1. A12 should stay "1" and A13 should stay "0" during mode set cycle. 2. A0 to A4, A7 to A11 should stay "0" during mode set cycle.

3. If don't set EMRS, DS is set to default (Full).

FEDD56V72161CTAPX-01


MD56V72161C-xxTAP

Output Driver Characteristics




Output Driver Strength=1/8

Output Driver Strength=1/4




FEDD56V72161CTAPX-01

MD56V72161C-xxTAP



Output Driver Strength=1/2

Output Driver Strength= Full (Default)



Burst Mode

Burst operation is the operation to continuously increase a column address inputted during read or write command. The upper bits select a column address block,

	<	Access order in column address block					
		Start Address		ss	Burst Type		
		(Lower bit)	BT=Sequential	BT=Interleave	
				A0			
	BL=2			0	0, 1	0, 1	
				1	1, 0	1, 0	
			A1	A0			
			0	0	0, 1, 2, 3	0, 1, 2, 3	
	BL=4		0	1	1, 2, 3, 0	1, 0, 3, 2	
			1	0	2, 3, 0, 1	2, 3, 0, 1	
			1	1	3, 0, 1, 2	3, 2, 1, 0	
÷		A2	A1	A0			
.bue	-	0	0	0	0, 1, 2, 3, 4, 5, 6, 7	0, 1, 2, 3, 4, 5, 6, 7	
Burst Length		0	0	1	1, 2, 3, 4, 5, 6, 7, 0	1, 0, 3, 2, 5, 4, 7, 6	
Burs		0	1	0	2, 3, 4, 5, 6, 7, 0, 1	2, 3, 0, 1, 6, 7, 4, 5	
	BL=8	0	1	1	3, 4, 5, 6, 7, 0, 1, 2	3, 2, 1, 0, 7, 6, 5, 4	
		1	0	0	4, 5, 6, 7, 0, 1, 2, 3	4, 5, 6, 7, 0, 1, 2, 3	
		1	0	1	5, 6, 7, 0, 1, 2, 3, 4	5, 4, 7, 6, 1, 0, 3, 2	
		1	1	0	6, 7, 0, 1, 2, 3, 4, 5	6, 7, 4, 5, 2, 3, 0, 1	
		1	1	1	7, 0, 1, 2, 3, 4, 5, 6	7, 6, 5, 4, 3, 2, 1, 0	
	A8~		A8~A0				
	BL=Full Page		0		0, 1 511		
	(512)		Yn		Yn, Yn+1 511, 0 Yn-1	Non Support	

MD56V72161C-xxTAP

READ / WRITE OPERATION

Bank

Activate

This SDRAM is organized as four independent banks of 1,048,576 words x 16 bits memory arrays. The A12 and A13 input is latched at the time of assertion of /RAS and /CAS to select the bank to be used for operation. The bank address A12 and A13 are latched at bank active, read, write, mode register set and precharge operations.

The bank activate command is used to select a random row in an idle bank. By asserting low on /RAS and /CS with desired row and bank address, a row access is initiated. The read or write operation can occur after a time

delay of tRCD(min) from the time of bank activation.

E	Bank Address					
	A12	A13	Bank			
	0	0	А			
	0	1	В			
	1	0	С			
	1	1	D			

<u>ACT</u>

CLK	n-1	l₄_]c
CKE	Н	Х
/CS		L
/RAS	х	L
/CAS	(Idle)	Н
/WE		н
A12, A13	Х	BA
A0 to A11	Х	RA

BA: Bank Address RA: Row Address (Page)

Precharge

The precharge operation is performed on an active bank by precharge command (PRE) with valid A12 and A13 of the bank to be precharged. The precharge command can be asserted anytime after tRAS(min) is satisfied from the bank active command in the desired bank. All bank can precharged at the same time by using precharge all command (PALL). Asserting low on /CS, /RAS and /WE with high on A10

|--|

CLK	n-1	n			
CKE	Н	Х			
/CS		L			
/RAS		L			
/CAS	(Page Open)	н			
/WE	open)	L			
A12,A13	Х	BA			
A10	Х	0			
A0 to A9, A11	Х	Х			
BA · Bank Address					

PALL		
CLK	n-1	l₄┐ =
CKE	Н	Х
/CS		L
/RAS	X (Page Open)	L
/CAS		Н
/WE		L
A12,A13	Х	Х
A10	Х	1
A0 to A9A11	Х	Х

BA: Bank Address

after all banks have satisfied tRAS(min) requirement, performs precharge on all banks. At the end of tRP after performing precharge to all banks, all banks are in idle state.

MD56V72161C-xxTAP

Write / Write with Auto-Precharge

The write command is used to write data into the SDRAM on consecutive clock cycles in adjacent address depending on burst length and burst sequence. By asserting low on /CS, /CAS and /WE with valid column address, a write burst is initiated. The data inputs are provided for the initial address in the same clock cycle as the burst write command. The input buffer is deselected at the end of the burst length, even through the internal writing can be completed yet. The writing can be completed by issuing a burst read and DQM for blocking data inputs or burst write in the same or another active bank. The burst stop command is valid at every burst length.


<u>WRT</u>		
CLK	n-1	_n _n
CKE	Н	Х
/CS		L
/RAS	X (Page Open)	Н
/CAS		L
/WE		L
A12, A13	Х	BA
A10	Х	0
A9, A11	Х	Х
A0 to A8	Х	СА
DQ	Х	D-in

BA: Bank Address CA: Column Address D-in: Data inputs

<u>WRTA</u>				
CLK	n-1			
CKE	Н	Х		
/CS				
/RAS	X	н		
/CAS	(Page Open)	L		
/WE	Open)	L		
A12, A13	Х	BA		
A10	Х	1		
A9, A11	Х	Х		
A0 to A8	Х	СА		
DQ	Х	D-in		

BA: Bank Address CA: Column Address D-in: Data inputs

Write Cycle



חס

MD56V72161C-xxTAP

Read / Read with Auto-Precharge


The read command is used to access burst of data on consecutive clock cycles from an active row in an active bank. The read command is issued by asserting low on /CS and /CAS with /WE being high on the positive edge of the clock. The bank must be active for at least tRCD(min) before the read command is issued. The first output appears in /CAS latency number of clock cycles after the issue of read command. The burst length, burst sequence and latency from the read command are determined by the mode register that is already programmed.

RD		
CLK	 n-1	l _€ ⊣≂
CKE	Н	Х
/CS	X	L
/RAS	X	Н
/CAS	(Page Open)	L
/WE	Open)	Н
A12, A13	Х	BA
A10	Х	0
A9, A11	Х	Х
A0 to A8	Х	СА
DQ	Х	Х
BA: Bank Addr	ess	

CA: Column Address

<u>RDA</u>		
CLK	 n-1	_f
CKE	Н	Х
/CS	X	L
/RAS	Х	Н
/CAS	(Page Open)	L
/WE	Openij	Н
A12, A13	Х	BA
A10	Х	1
A9, A11	Х	Х
A0 to A8	Х	СА
DQ	Х	Х

BA: Bank Address CA: Column Address



Read Cycle

MD56V72161C-xxTAP

Write / Write interrupt

When a new write command is issued to same bank during write cycle or another active bank, current burst write is terminated and new burst write start. When a new write command is issued to another bank during a write with auto-precharge cycle, current burst is terminated and a new write command start. Then, current bank is precharged after specified time. Don't issue a new write command to same bank during write with auto-precharge cycle.

CLK CL=2 or 3, BL=4, WM=Burst ICCD ICCD WRTa WRT Command WRTb DQ Da0 Db0 Db1 Dc0 Dc1 Dc2 Dc3 CL=2 or 3, BL=4, WM=Burst Auto Precharge Start Command WRTa WRTAD ACT tWR ICCD tRP DQ Db1 Db2 Db3 Da0 Da1 Db0 CL=2 or 3, BL=4, WM=Burst WRTA Command (WRTA ACT ACT ICCD tRRD Bank Address A В A В tWR tRP Burst Interrupt, Burst Write Auto Precharge Row Active Bank A Internal State Write Recovery tWR tRP Row Write Bank B Internal State Row Active Burst Write Auto Precharge Active Recovery DQ DA0 DA1 DB0 DB1 DB2 DB3

Write / Write interrupt cycle


FEDD56V72161CTAPX-01

MD56V72161C-xxTAP

Read / Read interrupt

When a new read command is issued to same bank during read cycle or another active bank, current burst read is terminated after the cycle same as /CAS latency and new burst read start. When a new read command is issued to another bank during a read with auto-precharge cycle, current burst is terminated after the cycle same as /CAS latency and a new read command start. Then, current bank is precharged after specified time. Don't issue a new read command to same bank during read with auto-precharge cycle.

Read / Read interrupt cycle




MD56V72161C-xxTAP

Write / Read interrupt

When a new read command is issued to same bank during write cycle or another active bank, current burst write is terminated and new burst read start. When a new read command is issued to another bank during a write with auto-precharge cycle, current burst is terminated and a new read command start. Then, current bank is precharged after specified time. Don't issue a new read command to same bank during write with auto-precharge cycle. DQ must be hi-Z till 1 or more clock from first read data.

Write / Read interrupt cycle




MD56V72161C-xxTAP

Read / Write interrupt

When a new write command is issued to same bank during read cycle or another active bank, current burst read is terminated and new burst write start. When a new write command is issued to another bank during a read with auto-precharge cycle, current burst is terminated and a new write command start. Then, current bank is precharged after specified time. Don't issue a new write command to same bank during read with auto-precharge cycle. DQ must be Hi-Z till 1 or more clock from new write command. Therefore, DQM must be high till 3 clocks from new write command.






FEDD56V72161CTAPX-01


MD56V72161C-xxTAP

Burst Stop

When a burst stop command is issued during read cycle, current burst read is terminated. The DQ is to Hi-Z after the cycle same as /CAS latency and page keep open. When a burst stop command is issued during write cycle, current burst write is terminated. The input data is ignored after burst stop command. Don't issue burst stop command during read with auto-precharge cycle or write with auto-precharge cycle.

<u>BST</u>		
CLK	 n-1	_n _n
CKE	Н	Х
/CS		L
/RAS	Х	Н
/CAS	(Burst)	н
/WE		L
A12, A13	Х	Х
A0 to A11	Х	Х






Read / Burst Stop cycle

MD56V72161C-xxTAP

Precharge Break

When a precharge command is issued to the same bank during read cycle or precharge all command is issued, current burst read is terminated and DQ is to Hi-Z after the cycle same as /CAS latency. The objected bank is precharged. When a precharge command is issued to the same bank during write cycle or precharge all command is issued, current burst write is terminated and the objected bank is precharged. The input data after precharge command is ignored.

Read / Precharge Break cycle




MD56V72161C-xxTAP

DQM Function

DQM masks input / output data at every byte. UDQM controls DQ8 to DQ15 and LDQM controls DQ0 to DQ7. During read cycle, DQM mask output data after 2 clocks. During write cycle, DQM mask input data at same clock.

Read / DQM Function




FEDD56V72161CTAPX-01

MD56V72161C-xxTAP

Clock Suspend

The read / write operation can be stopped by CKE temporarily. When CKE is set low, the next clock is ignored. When CKE is set low during read cycle, the burst read is stopped temporarily and the current output data is kept. When CKE is set high, burst read is resumed. When CKE is set low during write cycle, the burst write is stopped temporarily. When CKE is set high, burst write is resumed.



Read / Clock Suspend

25/44

LAPIS Semiconductor Co., Ltd.

MD56V72161C-xxTAP

FEDD56V72161CTAPX-01

REFRESH

The data of memory cells are maintained by refresh operation. The refresh operation is to activate all row addresses within a refresh time. The method that row addresses are activated by activate and precharge command is called RAS only refresh cycle. This method needs to input row address with activate command. But, auto-refresh and self refresh don't need to input address. Because, row addresses are generated in SDRAM automatically.

Auto Refresh

All memory area is refreshed by 4,096 times refresh command REF. The refresh command REF can be entered only when all the banks are in an idle state. SDRAM is in idle state after refresh cycle time tRCA.

The an	CLK	 n-1	_f
	CKE	Н	Н
	/CS		L
	/RAS	Х	L
	/CAS	(Idle)	L
	/WE		Н
	A12, A13	Х	Х
	A0 to A11	Х	Х

<u>REF</u>

Auto-Refresh Cycle CLK Command PALL Image: tree in the second second


Intensive Refresh

4,096 times refresh command can be entered every refresh time t_{REF} .

CLK					ļſ
State	Read or Write	Auto Refresh	Read or Write	Auto Refresh	
	tREF=64ms	REF x 4,096	tREF=64ms	REF x 4,096	;

Dispersed Refresh

Refresh command can be entered every 15.625µs (tREF 64ms / 4,096 cycles).



FEDD56V72161CTAPX-01

MD56V72161C-xxTAP


Self Refresh

When read or write is not operated in the long period, self refresh can reduce power consumption for refresh operation. Refresh operation is controlled automatically by refresh timer and row address counter during self refresh mode. All signals except CKE are ignored and data bus DQ is set Hi-Z during self refresh mode.

When CKE is set to high level, self refresh mode is finished. Then, CLK must be operated before 1 clock or more. And, maintain NOP condition within a period of tRCA(Min.) after CKE is set to be high level.

<u>SREF</u>		
CLK	n-1	l <mark>≼</mark> ⊣≃
CKE	Н	L
/CS		L
/RAS	Х	L
/CAS	(Idle)	L
/WE		Н
A12, A13	Х	Х
A0 to A11	Х	Х

Self Refresh Cycle



Notes : 1. When intensive refresh is used, 4,096 times refresh must be issued before and after the self refresh.


FEDD56V72161CTAPX-01

MD56V72161C-xxTAP

Power Down

SDRAM can be set to low power consumption condition with CKE function. CKE is reflected at 2 clocks later regardless /CAS latency. When CKE is set to low level, SDRAM go into power down mode. All signals except CKE are ignored and DQ is set to High impedance in this state. When CKE is set to high level, SDRAM exit power down mode. Then, Clock must be resumed before 2 or more clocks.

Power Down



Signal Condition in Power Down Mode

Signal	Input to SDRAM	Output from SDRAM
CLK	Don't Care	—
CKE	"L" level	—
/CS,/RAS, /CAS, /WE	Don't Care	_
A0 to A11, A12, A13	Don't Care	—
DQ0 to DQ15	Don't Care	High-Z
UDQM,LDQM	Don't Care	_
VCC,VCCQ,VSS,VSSQ	Power Supply	

Notes : 1. "Don't Care" means high or low level input.

Current State * ¹	/CS	/RAS	/CAS	/WE	ADDR Command		Action
ldle	Н	Х	Х	Х	Х	NOP	NOP
	L	Н	Н	Х	Х	NOP/BST	NOP
	L	Н	L	Н	BA, CA, A10	RD/RDA	ILLEGAL ^{*2}
	L	Н	L	L	BA, CA, A10	WRT/WRTA	ILLEGAL ^{*2}
	L	L	Н	Н	BA, RA	ACT	Row Active
	L	L	Н	L	BA, A10	PRE/PALL	NOP *3
	L	L	L	Н	Х	REF	Auto-Refresh or Self-Refresh *4
	L	L	L	L	V, A12=0, A13=0	MRS	Mode Register Set *4
	L	L	L	L	V, A12=1, A13=0	EMRS	Extended Mode Register Set *4,10
Row	Н	Х	Х	Х	Х	NOP	NOP
Active	L	Н	Н	Х	Х	NOP/BST	NOP
	L	Н	L	Н	BA, CA, A10	RD/RDA	Read
	L	Н	L	L	BA, CA, A10	WRT/WRTA	Write
	L	L	Н	Н	BA, RA	ACT	ILLEGAL ^{*6}
	L	L	Н	L	BA, A10	PRE/PALL	Precharge
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL
Read	Н	Х	Х	Х	Х	NOP	Continue Row Active after Burst ends
	L	Н	Н	Н	Х	NOP	Continue Row Active after Burst ends
	L	Н	Н	L	Х	BST	Term Burst> Row Active
	L	Н	L	Н	BA, CA, A10	RD/RDA	Term Burst, start new Burst Read
	L	Н	L	L	BA, CA, A10	WRT/WRTA	Term Burst, start new Burst Write
	L	L	Н	Н	BA, RA	ACT	ILLEGAL *6
	L	L	Н	L	BA, A10	PRE/PALL	Term Burst, execute Row Precharge
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL
Write	Н	Х	Х	Х	Х	Х	Continue Row Active after Burst ends
	L	Н	Н	Н	Х	Х	Continue Row Active after Burst ends
	L	Н	Н	L	Х	Х	Term Burst> Row Active
	L	Н	L	Н	BA, CA, A10	CA, A10	Term Burst, start new Burst Read
	L	Н	L	L	BA, CA, A10	CA, A10	Term Burst, start new Burst Write
	L	L	Н	Н	BA, RA	RA	ILLEGAL *6
	L	L	Н	L	BA, A10	A10	Term Burst, execute Row Precharge
	L	L	L	Н	х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL

FUNCTION TRUTH TABLE (Table 1) (1/3)

MD56V72161C-xxTAP

Current State ^{*1}	/CS	/RAS	/CAS	/WE	ADDR	Command	Action
Read with	Н	Х	Х	Х	Х	NOP	Continue Burst to End and enter Row Precharge
Auto	L	Н	Н	Н	X NOP C		Continue Burst to End and enter Row Precharge
Precharg	L	Н	Н	L	X BST II		ILLEGAL
е	L	Н	L	Н	BA, CA, A10	RD/RDA	ILLEGAL *7
	L	Н	L	L	BA, CA, A10	WRT/WRTA	ILLEGAL *7
	L	L	Н	Н	BA, RA	ACT	ILLEGAL *6
	L	L	Н	L	BA, A10	PRE/PALL	ILLEGAL *8
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL
Write with	Н	Х	Х	Х	Х	NOP	Continue Burst to End and enter Row Precharge
Auto	L	Н	Н	Н	Х	NOP	Continue Burst to End and enter Row Precharge
Precharge	L	Н	Н	L	Х	BST	ILLEGAL
	L	Н	L	Н	BA, CA, A10	RD/RDA	ILLEGAL *7
	L	Н	L	L	BA, CA, A10	WRT/WRTA	ILLEGAL *7
	L	L	Н	Н	BA, RA	ACT	ILLEGAL *6
	L	L	Н	L	BA, A10	PRE/PALL	ILLEGAL *8
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL
Precharge	Н	Х	Х	Х	Х	NOP	Idle after t _{RP}
	L	Н	Н	Н	Х	NOP	Idle after t _{RP}
	L	Н	Н	L	Х	BST	ILLEGAL
	L	Н	L	Н	BA, CA, A10	RD/RDA	ILLEGAL ^{*2}
	L	Н	L	L	BA, CA, A10	WRT/WRTA	ILLEGAL *2
	L	L	Н	Н	BA, RA	ACT	ILLEGAL ^{*6}
	L	L	Н	L	BA, A10	PRE/PALL	ILLEGAL *3
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL
Write	Н	Х	Х	Х	Х	NOP	Row Active after t _{WR}
Recovery	L	Н	Н	Н	Х	NOP	Row Active after t _{WR}
"g	L	Н	Н	L	Х	BST	ILLEGAL
	L	Н	L	Н	BA, CA, A10	RD/RDA	ILLEGAL ^{*2}
	L	Н	L	L	BA, CA, A10	WRT/WRTA	ILLEGAL ^{*2}
	L	L	Н	Н	BA, RA	ACT	ILLEGAL *6
	L	L	Н	L	BA, A10	PRE/PALL	ILLEGAL *8
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL

FUNCTION TRUTH TABLE (Table 1) (2/3)

FUNCTION TRUTH TABLE (Table 1) (5/5)							
Current State ^{*1}	/CS	/RAS	/CAS	/WE	ADDR	Command	Action
Write	Н	Х	Х	Х	Х	NOP	enter Row Precharge after t _{WR}
Recovery	L	Н	Н	Н	Х	NOP	enter Row Precharge after t _{WR}
in Auto	L	Н	Н	L	Х	BST	ILLEGAL
Precharge	L	Н	L	Н	BA, CA, A10	RD/RDA	ILLEGAL *7
Ŭ	L	Н	L	L	BA, CA, A10	WRT/WRTA	ILLEGAL *7
	L	L	Н	Н	BA, RA	ACT	ILLEGAL *6
	L	L	Н	L	BA, A10	PRE/PALL	ILLEGAL *8
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL
Auto	Н	Х	Х	Х	Х	NOP	Idle after t _{RCA}
Refresh	L	Н	Н	Н	Х	NOP	Idle after t _{RCA}
	L	Н	Н	L	Х	BST	ILLEGAL
	L	Н	L	Н	BA, CA, A10	RD/RDA	ILLEGAL
	L	Н	L	L	BA, CA, A10	WRT/WRTA	ILLEGAL
	L	L	Н	Н	BA, RA	ACT	ILLEGAL
	L	L	Н	L	BA, A10	PRE/PALL	ILLEGAL
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL
Mode	Н	Х	Х	Х	Х	NOP	Idle after I _{MRD}
Register	L	Н	Н	Н	Х	NOP	Idle after I _{MRD}
Access	L	Н	Н	L	Х	BST	ILLEGAL
	L	Н	L	Н	BA, CA, A10	RD/RDA	ILLEGAL
	L	Н	L	L	BA, CA, A10	WRT/WRTA	ILLEGAL
	L	L	Н	Н	BA, RA	ACT	ILLEGAL
	L	L	Н	L	BA, A10	PRE/PALL	ILLEGAL
	L	L	L	Н	Х	REF	ILLEGAL
	L	L	L	L	Х	MRS/EMRS	ILLEGAL

FUNCTION TRUTH TABLE (Table 1) (3/3)

ABBREVIATIONS

ADDR = Address RA = Row Address NOP = No OPeration command BA = Bank Address CA = Column Address V = Value of Mode Register Set

*Notes :1. All inputs are enabled when CKE is set high for at least 1 cycle prior to the inputs.

- 2. RD/RDA or WRT/WRTA command to same bank is forbidden. But RD/RDA or WRT/WRTA command to activated page in another bank is valid.
- 3. PRE command to another activated bank is valid. PALL command is valid to only activated bank.
- 4. Illegal if any bank is not idle.
- 5. RD/RDA or WRT/WRTA command to activated bank is valid after tRCD(min.) from ACT command.
- 6. Activate command to the same bank is forbidden. But activate command to another bank in idle state is valid.
- 7. RD/RDA or WRT/WRTA command to same bank is forbidden. But RD/RDA or WRT/WRTA command to activated page in another bank is valid.
- 8. PRE to same bank is forbidden. PRE to another bank must be issued after tRAS(min.). PALL command is forbidden.
- 9. Write recovery states means a period from last data to the time that tWR(min.) passed.

MD56V72161C-xxTAP

Current State	CKE	CKE	/CS	/RAS	/CAS	/WE	ADDR	Action
n-1	n-1	n	n	n	n	n	n	, (61011
All Banks Idle	Н	Н	Х	Х	Х	Х	Х	Refer to Table 1
(ABI)	Н	L	Н	Х	Х	Х	Х	Enter Power Down
	Н	L	L	Н	Н	Н	Х	Enter Power Down
	Н	L	L	Н	Н	L	Х	ILLEGAL
	Н	L	L	Н	L	Х	Х	ILLEGAL
	Н	L	L	L	Н	Н	BA, RA	Enter Active Power Down after Activate
	Н	L	L	L	Н	L	Х	ILLEGAL
	Н	L	L	L	L	Н	Х	Enter Self Refresh ^{*1}
	Н	L	L	L	L	L	BA, V	Enter Power Down after MRS
	L	Х	Х	Х	Х	Х	Х	INVALID
Self Refresh	Н	Х	Х	Х	Х	Х	Х	INVALID
	L	н	Н	Х	Х	Х	Х	Exit Self Refresh> ABI *2
	L	н	L	Н	Н	Н	Х	Exit Self Refresh> ABI *2
	L	Н	L	Н	Н	L	Х	ILLEGAL
	L	н	L	Н	L	Х	Х	ILLEGAL
	L	н	L	L	Х	Х	Х	ILLEGAL
	L	L	Х	Х	Х	Х	Х	NOP (Maintain Self Refresh)
Power Down	Н	Х	Х	Х	Х	Х	Х	INVALID
	L	н	Х	Х	Х	Х	Х	Exit Power Down> ABI *3
	L	L	Х	Х	Х	Х	Х	NOP (Continue Power Down)
Active Power	Н	Х	Х	Х	Х	Х	Х	INVALID
Down	L	н	Х	Х	Х	Х	Х	Exit Active Power Down> Row Active *3
	L	L	Х	Х	Х	Х	Х	NOP (Continue Active Power Down)
Row Active	Н	н	Х	Х	Х	Х	Х	Refer to Table 1
	Н	L	Н	Х	Х	Х	Х	Enter Active Power Down
	Н	L	L	Н	Н	Н	Х	Enter Active Power Down
	Н	L	L	Н	Н	L	Х	ILLEGAL
	Н	L	L	Н	L	Х	Х	Clock Suspension (Refer to Table 1)
	Н	L	L	L	Н	Х	Х	Clock Suspension (Refer to Table 1)
	Н	L	L	L	L	Х	Х	ILLEGAL
	L	Х	Х	Х	Х	Х	Х	INVALID
Any State Other	Н	Н	Х	Х	Х	Х	Х	Refer to Table 1
than Listed	Н	L	Х	Х	Х	Х	Х	Begin Clock Suspend Next Cycle
Above	L	Н	Х	Х	Х	Х	Х	Enable Clock of Next Cycle
	L	L	Х	Х	Х	Х	Х	Continue Clock Suspension

FUNCTION TRUTH TABLE for CKE (Table 2)

ABBREVIATIONS


ADDR = Address RA = Row Address V = Value of Mode Register Set BA = Bank Address ABI = All Banks Idle NOP = No OPeration command

*Notes :1. Self Refresh can be entered only when all the banks are in an idle state.

2. tRCA must be set after exit self refresh.

3. New command is enabled in the next clock.


SIMPLIFIED STATE DIAGRAM




MD56V72161C-xxTAP

TIMING CHART

Synchronous Characteristics




(input).



Notes : 1. It is advisable that UDQM and LDQM are set to high for set DQ to high impedance during power on sequence.


Power on Sequence

MD56V72161C-xxTAP




Notes : 1. V = Value of mode register, Rx = Row Address, Bx = Bank Address NOP command or High or Low

2. It is advisable that UDQM to LDQM are set to be high level for setting DQ to high impedance during power on sequence.




Mode Register Set cycle


Notes : 1. V = Value of mode register, Rx = Row Address, Bx = Bank Address = NOP command or High or Low





= NOP command or High or Low level, CKE = High level



Bank Interleave • Write with Auto Precharge Cycle (CL=2, BL=4, WM=Burst)









Burst Read • Single Write Cycle (CL=2, BL=4,WM=Single)


MD56V72161C-xxTAP






Byte Read / Byte Write Cycle (CL=2, BL=8, WM=Burst)

Notes : 1. Cx = Column Address, Bx = Bank Address = NOP command or High or Low level, CKE = High level, []= Invalid Data Input




Clock Suspend • Read / Write Cycle (CL=3, BL=4, WM=Burst)




FEDD56V72161CTAPX-01

MD56V72161C-xxTAP




Notes : $1. \underline{Rx} = Row Address, Bx = Bank Address$ = NOP command or High or Low level, CKE = High level, [] = Invalid Data Input



Self Refresh Cycle


MD56V72161C-xxTAP



= High or Low level

MD56V72161C-xxTAP

PACKAGE DIMENSIONS



Notes for Mounting the Surface Mount Type Package

The surface mount type packages are very susceptible to heat in reflow mounting and humidity absorbed in storage. Therefore, before you perform reflow mounting, contact a ROHM sales office for the product name, package name, pin number, package code and desired mounting conditions (reflow method, temperature and times).

MD56V72161C-xxTAP

REVISION HISTORY

		Page		
Document No.	Date	Previous Edition	Current Edition	Description
FEDD56V72161CTAPX-01	Jan. 16, 2019	_	_	Final edition 1 (from FEDD56V72161CTAP-03)

<u>Notes</u>

- 1) The information contained herein is subject to change without notice.
- 2) Although LAPIS Semiconductor is continuously working to improve product reliability and quality, semiconductors can break down and malfunction due to various factors. Therefore, in order to prevent personal injury or fire arising from failure, please take safety measures such as complying with the derating characteristics, implementing redundant and fire prevention designs, and utilizing backups and fail-safe procedures. LAPIS Semiconductor shall have no responsibility for any damages arising out of the use of our Products beyond the rating specified by LAPIS Semiconductor.
- 3) Examples of application circuits, circuit constants and any other information contained herein are provided only to illustrate the standard usage and operations of the Products. The peripheral conditions must be taken into account when designing circuits for mass production.
- 4) The technical information specified herein is intended only to show the typical functions of the Products and examples of application circuits for the Products. No license, expressly or implied, is granted hereby under any intellectual property rights or other rights of LAPIS Semiconductor or any third party with respect to the information contained in this document; therefore LAPIS Semiconductor shall have no responsibility whatsoever for any dispute, concerning such rights owned by third parties, arising out of the use of such technical information.
- 5) The Products are intended for use in general electronic equipment (i.e. AV/OA devices, communication, consumer systems, gaming/entertainment sets) as well as the applications indicated in this document.
- 6) The Products specified in this document are not designed to be radiation tolerant.
- 7) For use of our Products in applications requiring a high degree of reliability (as exemplified below), please contact and consult with a LAPIS Semiconductor representative: transportation equipment (i.e. cars, ships, trains), primary communication equipment, traffic lights, fire/crime prevention, safety equipment, medical systems, servers, solar cells, and power transmission systems.
- 8) Do not use our Products in applications requiring extremely high reliability, such as aerospace equipment, nuclear power control systems, and submarine repeaters.
- 9) LAPIS Semiconductor shall have no responsibility for any damages or injury arising from non-compliance with the recommended usage conditions and specifications contained herein.
- 10) LAPIS Semiconductor has used reasonable care to ensure the accuracy of the information contained in this document. However, LAPIS Semiconductor does not warrant that such information is error-free and LAPIS Semiconductor shall have no responsibility for any damages arising from any inaccuracy or misprint of such information.
- 11) Please use the Products in accordance with any applicable environmental laws and regulations, such as the RoHS Directive. For more details, including RoHS compatibility, please contact a ROHM sales office. LAPIS Semiconductor shall have no responsibility for any damages or losses resulting non-compliance with any applicable laws or regulations.
- 12) When providing our Products and technologies contained in this document to other countries, you must abide by the procedures and provisions stipulated in all applicable export laws and regulations, including without limitation the US Export Administration Regulations and the Foreign Exchange and Foreign Trade Act.
- 13) This document, in part or in whole, may not be reprinted or reproduced without prior consent of LAPIS Semiconductor.

Copyright 2019 LAPIS Semiconductor Co., Ltd.

LAPIS Semiconductor Co., Ltd.

2-4-8 Shinyokohama, Kouhoku-ku, Yokohama 222-8575, Japan http://www.lapis-semi.com/en/