SPICoder™ UR5HCSPI Zero-Power™ Keyboard Encoder & Power Management IC for H/PCs

HID & SYSTEM MANAGEMENT PRODUCTS, H/PC IC FAMILY

DESCRIPTION

The SPICoder™ UR5HCSPI keyboard encoder and power management IC is designed specifically for handheld PCs (H/PCs). The off-the-shelf UR5HCSPI will readily work with CPUs designed for Windows CE®, saving OEMs significant development time and money as well as minimizing time-to-market for the new generations of handheld products.

Three main design features of the UR5HCSPI make it the ideal companion for the new generation of Windows CE® -compatible, single-chip computers: low-power consumption; real estate-saving size; and special keyboard modes.

"Quasi" Zero-Power™ consumption (less than 2µA @ 3V), a must for H/PCs, provides the host system with both power management and I/O flexibility, with almost no battery drainage.

Finally, special keyboard modes and built-in power management features allow the SPICoder™ to operate in harmony with the power management modes of Windows CE®, resulting in more user flexibility and longer battery life.

The UR5HCSPI also offers programmable features for wake-up keys and general purpose I/O pins.

FEATURES

- SPI-compatible keyboard encoder and power management IC with other interfaces available
- Compatible with Windows CE[®] keyboard specification
- Zero-Power[™] typically consuming less than 2µA, between 3-5V
- Offers overall system power management capabilities

- Compatible with "system-on silicon" CPUs for H/PCs
- Special keyboard and power management modes for H/PCs, including programmable "wake-up" keys
- Scans, debounces, and encodes an 8 x 12 matrix and controls discrete switches and LED indicators
- · Custom versions available


APPLICATIONS


- StrongARM™ Handheld PCs
- Windows CE® Platforms
- Web Phones

1

- Personal Digital Assistants (PDAs)
- Wearable Computers
- Internet Appliance

PIN ASSIGNMENTS






SPICoder is a trademark of Semtech Corp. All other trademarks belong to their respective companies.



ORDERING CODE		
Package Options 44-pin, Plastic PLCC	Pitch in mm's 1.27 mm	TA=-20° C to +85° C UR5HCSPI-XX-FN
44-pin, Plastic QFP	0.8 mm	UR5HCSPI-XX-FB
Other Materials	Туре	Order number
SPICoder™	Testing Board	ASY5-SPI-XXX
Note 1: XX=Optional Customiz	zation, XXX= Denotes Revision	number

BLOCK DIAGRAM





PIN DEFINITIONS

FUNCTIONAL DESCRIPTION

The UR5HCSPI consists functionally of five major sections (see the Functional Diagram on page 2). These are the Keyboard Scanner and State control, the Programmable I/O, the SPI Communication Channel, the System Monitor and the Power Management unit. All sections communicate with each other and operate concurrently.

PIN DEFINITION	5			
Mnemonic	PLCC	QFP	Tyne	Name and Function
VCC	44	38	 турс	Power Supply: 3-5V
VSS	22		 	Ground
VX	4	43	 -i	Tie to VCC
OSCI	43	37	 T	Oscillator input
OSCO	42	36	0	Oscillator output
_RESET	1	41	1	Reset: apply 0V to provide orderly
			 	start-up
MISO	34	29	Ο	SPI Interface Signals
MOSI	35	30	I	
SCK	36	31	I	
SS	37	32	 	Slave Select: If not used tie to VSS
_IOTEST	24	18	Ο	Wake-Up Control Signals
_WKU	2	42	 	
R0-R4	13-17	8-12	I	Row Data Inputs
R5-R7	<u>19-21</u>	<u> 13-15</u>	 	Port provides internal pull-up resistors
C0-C5	12-7	7-2	Ο	Column Select Outputs:
C6-C7	6-5	1,44	Ο	
<u>C8-C9</u>	31-30	<u> 26-25</u>	 O	
				Multi-function pins
C10/WUKO	29	24	I/O	C10 & "Wake-Up Keys Only" imput
C11/_LID	28_	23	 <u> </u>	
				Miscellaneous functions
LED2	27	21	I/O	LED2 output
LED1	26	20	I/O	LED1 output
LED0	25_	19	 I/O	
XSW	33	28	1	External discrete switch
SWO	32_	27	 	Discrete switch
				Power Management Pins
_ATN	38	33	O	CPU Attention Output
_PWR_OK	39_	34	 	Power OK Input
NC	3,18	39-40		No Connects: these pins are unused
	23,40	16,22		
NC0	41_	35	 	NC0 should be tied to VSS or GND

Note 1: An underscore before a pin mnemonic denotes an active low signal.



PIN DESCRIPTIONS

VCC and VSS

VCC and VSS are the power supply and ground pins. The UR5HCSPI will operate from a 3-5 Volt power supply. To prevent noise problems, provide bypass capacitors and place them as close as possible to the IC with the power supply. VX, where available, should be tied to Vcc.

OSCI and OSCO

OSCI and OSCO provide the input and output connections for the onchip oscillator. The oscillator can be driven by any of the following circuits:

- Crystal
- Ceramic Resonator
- External Clock Signal The frequency of the on-chip oscillator is 2 MHz.

_RESET

A logic zero on the _RESET pin will force the UR5HCSPI into a known start-up state. The reset signal can be supplied by any of the following circuits:

- RC
- Voltage monitor
- Master system reset

MOSI, MISO, SCK, SS, ATN

These five signals implement the SPI interface. The device acts as a slave on the SPI bus. The _SS (Slave Select) pin should be tied to ground if not used by the SPI master. The _ATN pin is asserted low each time the UR5HCSPI has a packet ready for delivery. For a more detailed description, refer to the SPI Communication Channel section on page 9.

_IOTEST and _WKU

"Input Output Test" and "Wake Up" pins control the stop mode exit of the device. The designer can connect any number of active low signals to these two pins through a 17K resistor, in order to force the device to exit the stop mode. A sample circuit is shown on page 15 of this document.

All the signals are "wire-anded." When any one of these signals is not active, it should be floating (i.e., these signals should be driven from "open-collector" or "open-drain" outputs). Other configurations are possible; contact Semtech.

R0-R 7

The R0-R7 pins are connected to the rows of the scanned matrix. Each pin provides an internal pullup resistor, eliminating the need for external components.

C0-C9

C0 to C9 are bi-directional pins connected to the columns of the scanned matrix. When a column is selected, the pin outputs an active low signal. When the column is deselected, the pin turns into high-impedance.

C10/WUKO

The C10/WUKO pin acts alternatively as column scan output and as an input. As an input, the pin detects the "Wake-Up Keys Only" signal, typically provided by the host CPU to indicate that the user has turned the unit off. When the device detects an active high state on this pin, it feeds this information into the "Keyboard State Control" unit, in order to disable the keyboard and enable the programmed wake-up keys.

C11/_LID

The C11/_LID pin acts in a similar manner to the C10/WUKO. This pin is typically connected to the LID latch through a 150K resistor, in order to detect physical closing of the device cover. When the pin detects an active low state in this input, it feeds this information into the "Keyboard State Control" unit, in order to disable keys inside the case and enable only switches located physically on the outer body of the H/PC unit.

LED0, LED1 and LED2

These three pins provide an active low drive for LED indicators. The programming of these pins is explained in the LEDs section on page 8 of this document.



PIN DESCRIPTIONS, (CON'T)

XSW

The XSW pin is dedicated to an external switch. This pin is handled differently than the rest of the switch matrix and is intended to be connected to a switch physically located on the outside of the unit.

SWO

The SW0 pin is a dedicated input pin for a switch.


PWR_OK

The PWR_OK is an active low pin that monitors the battery status of the unit. When the UR5HCSPI detects a transition from high to low on this pin, it will immediately enter the STOP mode, turn the LED off and remain in this state until the batteries of the unit are replaced and the signal is deasserted.

THE WINDOWS CE® KEYBOARD

The following illustration shows a typical implementation of a Windows CE® keyboard.

Windows CE® does not support the following keyboard keys typically found on desktop and laptop keyboards:



- INSERT
- SCROLL LOCK
- PAUSE
- NUM LOCK
- Function Keys (F1-F12)
- PRINT SCREEN

If the keyboard implements the Windows key, the following key combinations are supported in the Windows CE® environment:

Key Combination	Result
Windows Windows+K Windows+I Windows+C Windows+E Windows+R Windows+H	Open Start Menu Open Keyboard Tool Open Stylus Tool Open Control Panel Explore the H/PC Display the Run Dialog Box Open Windows CE® Help
Ctrl+Windows+A	Select all on desktop



"GHOST" KEYS

In any scanned contact switch matrix, whenever three keys defining a rectangle on the switch matrix are pressed at the same time, a fourth key positioned on the fourth corner of the rectangle is sensed as being pressed. This is known as the "ghost" or "phantom" key problem.




Figure 1: "Ghost" or "Phantom" Key Problem

Although the problem cannot be totally eliminated without using external hardware, there are methods to neutralize its negative effects for most practical applications. Keys that are intended to be used in combinations should be placed in the same row or column of the matrix, whenever possible. Shift Keys (Shift, Alt, Ctrl, Window) should not reside in the same row (or column) as any other keys. The UR5HCSPI has built-in mechanisms to detect the presence of "ghost" keys.

KEYBOARD SCANNER

The encoder scans a keyboard organized as an 8 row by 12 column matrix for a maximum of 96 keys. Smaller size matrixes can also be accommodated by simply leaving unused pins open. The UR5HCSPI provides internal pull-ups for the Row input pins. When active, the encoder selects one of the column lines (C0-C13) every 512 µS and then reads the row data lines (R0-R7). A key closure is detected as a zero in the corresponding position of the matrix.

A complete scan cycle for the entire keyboard takes approximately 9.2 mS. Each key found pressed is debounced for a period of 20 mS. Once the key is verified, the corresponding key code(s) are loaded into the transmit buffer of the SPI communication channel.

N-KEY ROLLOVER

In this mode, the code(s) corresponding to each key press are transmitted to the host system as soon as that key is debounced, independent of the release of other keys.

When a key is released, the corresponding break code is transmitted to the host system. There is no limitation to the number of keys that can be held pressed at the same time. However, two or more key closures, occurring within a time interval of less than 5mS, will set an error flag and will not be processed. This feature is to protect against the effects of accidental key presses.



KEYBOARD STATES

These states of operation refer only to the keyboard functionality and, although they are related to power states, they are also independent of them.

"Send All Keys"

Entry Conditions: Power on reset, soft reset, PWR_OK =1, {(LID=1) AND (WUKO=0)}

Exit Conditions: PWR_OK = 0 -> "Send No Keys" (WUKO=1) AND (Key Press) -> "Send Wake-Up Keys Only" (LID = 0) AND (WUKO=0) AND (Key Press) -> "Send XSW Key Only"

Description: This is the UR5HCSPI's normal state of operation, accepting and transmitting every key press to the system. This state is entered after the power-on and is sustained while the unit is being used.

"Send Wake-Up Keys Only"

Entry Conditions: (WUKO=1) AND (Key or Switch press)

Exit Conditions: Soft Reset -> "Send All Keys"PWR_OK = 0 -> "Send No Keys"

Description: This state is entered when the user turns the unit off. A signal line driven by the host will notify the UR5HCSPI about this state transition. While in this state, the UR5HCSPI will transmit only keys programmed to be wake-up keys to the system. It is not necessary for the UR5HCSPI to detect this transition in real time, since it does not effect any operation besides buffering keystrokes.




Figure 2: The UR5HCSPI implements four modes of keyboard and switch operation.

"Send No Keys"

Entry Conditions: PWR_OK transition from high to low

Exit Conditions: (PWR_OK = 1) AND (Matrix key pressed OR Switch OR _WKUP)

Description: This state is entered when a PWR_OK signal is asserted (transition high to low), indicating a critically low level of battery voltage. The PWR_OK signal will cause an interrupt to the UR5HCSPI, which guarantees that the transition is performed in real time. While in this state, the UR5HCSPI will perform as follows:

- 1. The LED will be turned off. Nevertheless, its state is saved and will be restored after exiting the disabled state (change of batteries).
- 2. The UR5HCSPI will enter the STOP mode for maximum energy conservation.

- 3. Stop mode time-out entry will be shortened to further conserve energy.
- 4. While in this state all interrupts are disabled. The UR5HCSPI will exit this state on the next interrupt event that detects the PWR_OK line has been de-asserted.

"Send XSW Key Only"

Entry Condition: (LID=0) AND (WUKO=0) AND (Key Press)

Exit Condition: (LID=1) AND (WUKO=0) AND (Key Press) -> "Send All Keys"PWR_OK = 0 -> "Send No Keys" (WUKO = 1) AND (Key Press) -> "Send Wake Up Keys Only"

Description: This state is entered upon closing the lid of the device. While in this state, the encoder will transmit only the XSW key, which is located outside the unit. This feature is designed to accommodate buttons on the outside of the box, such as a microphone button, that need to be used while the lid is closed.



KEY CODES

Key codes range from 01H to 73H and are arranged as follows:

Make code = column_number * 8 + row_number + 1

Break code = Make code OR 80H

Discrete Switches transmit the following codes:

XSW = 71H

SW0 = 72H

LED MODES




Figure 3: The behavior of an LED using the settings 1: LED on; 0: LED off.

The UR5HCSPI provides three LED pins. There are three LED modes: off, on, and blinking. The LED can be individually set to one of these modes. In the Blinking Mode, both the on-interval and the off-interval can be individually set. Additionally, a meta blink count and meta blink interval may be specified. This describes an interval of a different length which may be inserted after each specified number of blinks. All the intervals are based on a 1/16th of a second duration. When the LED is on or blinking, the SPICoder™ will not enter the STOP Mode unless the PWR_OK signal is asserted low. In this case, the device will save the status of the LED and turn it off. The default LED mode is off.

The above timing chart describes the behavior of an LED using these settings,1: LED on; 0: LED off.



SPI COMMUNICATION CHANNEL

SPI data transfers can be performed at a maximum clock rate of 500 KHz. When the UR5HCSPI asserts the _ATN signal to the host Master, the data will have already been loaded into the data register waiting for the clocks from the master. The Slave Select (SS) line can be tied permanently to Ground if the UR5HCSPI is the only slave device in the SPI network. One _ATN signal is used per each byte transfer. If the host fails to provide clock signals for successive bytes in the data packet within 120 mS, the transmission will be aborted and a new session will be initiated by asserting a new ATN signal. In this case, the whole packet will be re-transmitted.

If the SPI transmission fails 20 times consecutively, the synchronization between the master and slave may be lost. In this case, the UR5HCSPI will enter the reset state.

The UR5HCSPI implements the SPI communication protocol according to the following diagram:

CPOL = 0 ----- SCK line idles in low state

CPHA = 1 ----- SS line is an output enable control




Figure 4: SPI Communication Protocol

When the host sends commands to the keyboard, the UR5HCSPI requires that the minimum and maximum intervals between two successive bytes be 200 µS and 5 mS respectively.



Figure 5: Transmitting Data Waveforms:



Figure 6: Receiving Data Waveforms



DATA/COMMAND BUFFER

The UR5HCSPI implements a data buffer that contains the key code/command bytes waiting to be transmitted to the host. If the data buffer is full, the whole buffer will be cleared and an "Initialize" command will be sent to the host. At the same time, the keyboard will be disabled until the "Initialize" or "Initialize Complete" command from the host is received.


POWER MANAGEMENT UNIT

The UR5HCSPI supports two modes of operation. The following table lists the typical and maximum supply current (no DC loads) for each mode at 3.3 Volts (+/- 10%).

Current	Typical	Max	Unit	Description
RUN	1.5 1	3.0	mA	Entered only while data/commands are in process and if the LEDs are blinking
STOP	2.0	20	μΑ	Entered after 125 mS of inactivity if LEDs islow

Power consumption of the keyboard sub-system will be determined primarily by the use of the LEDs. While the UR5HCSPI is in the STOP mode, an active low Wake-Up Output from the Master must be connected to the edge-sensitive _WKU pin of the UR5HCSPI. This signal will be used to wake up the UR5HCSPI in order to receive data from the Master host. The Master host will have to wait a minimum of 5 mS prior to providing clocks to the UR5HCSPI. The UR5HCSPI will enter the STOP mode after a 125 mS period of keypad and/or host communications inactivity, or anytime the PWR_OK line is asserted low by the host. Note that while one or more keys are held pressed, the UR5HCSPI will not enter the STOP mode until every key is released.

Figure 7: The power states of the UR5HCSPI





COMMUNICATION PROTOCOL

There are eight commands that may be sent from the UR5HCSPI to the host, and ten commands that may be sent from the host to the UR5HCSPI.

Each command from UR5HCSPI to the host is composed of a sequence of codes. All commands start with <CONTROL> code (80H) and end with LRC code (see the description of the LRC calculation on page 12). Command details are listed below.

Commands to the Host - Summary

Command Name	Code	Description	
Initialize Request	AOH	Sent to the host when the data buffer is full	
Initialize Complete	A1H	Issued upon completion of the "Initialize" command issued by the host	
Heartbeat Response	A2H	H Response to "Heartbeat Request" issued by the host	
Identification Response	F2H	H Response to "Identification Request" issued by the host	
LED Status Report	A3H	Response to "LED Status Request"	
Resend Request	A5H	Issued upon error during the reception of a packet	

LRC CALCULATION

The LRC is calculated for the whole packet, including the Command Code and the Command Prefix. The LRC is calculated by first taking the bitwise exclusive OR of all bytes from the message. If the most significant bit (MSB) of the LRC is set, the LRC is modified by clearing the MSB and changing the state of the next most significant bit. Thus, the Packet Check Byte will never consist of a valid LRC with the most significant bit set.

COMMANDS TO THE HOST ANALYTICALLY

Initialize Request

<CONTROL> 80H <INIT> A0H <LRC> 20H

The UR5HCSPI will send the Initialize Request Command to the host when its data buffer is full.

Initialization Complete

<CONTROL> 80H <INIT COMPLETE> A1H <LRC> 21H

The UR5HCSPI wil send the Initialize Complete Report to the host when it finishes the initialization caused by Initialize Command from the host.

Heartbeat Response

<CONTROL> 80H <ONLINE> A2H <I RC> 22H

The UR5HCSPI will send the Heartbeat Response to the host when it receives the Heartbeat Request Command from the host.

Identification Response

 <CONTROL>
 80H

 <ID>
 F2H

 <Vendor>
 02H
 --- USAR

 <Revision>
 08H
 --- Rev 0.8A

 <Switch>
 00H
 --- Rev 0.8A

The UR5HCSPI will send the Identification Response to the host when it receives the Identification Request Command from the host.



LRC CALCULATION, (CON'T)

The following C language function is an example of an LRC calculation program. It accepts two arguments: a pointer to a buffer and a buffer length. Its return value is the LRC value for the specified buffer.

```
char Calculate LRC (char buffer,
size buffer)
char LRC:
size_t index;
/*
* Init the LRC using the first two
message bytes.
LRC = buffer [0] ^ buffer [1];
* Update the LRC using the
remainder of the buffer.
*/
for (index = 2; index < buffer; index
 LRC ^ = buffer[index];
* If the MSB is set then clear the
MSB and change the next most
significant bit
*/
if (LRC & 0x80)
LRC ^ = 0xC0:
/* * Return the LRC value for the
buffer.*/}
```

COMMANDS FROM THE UR5HCSPI TO THE HOST, (CON'T)

```
LED Status Report
                           H08
    <CONTROL>
    <LFD>
                           А3Н
    <Status 0>
                                  LED0 status:(0=OFF; 1=ON;
                           ххH
                                  2=BLINKING; 3=NO LED MODE)
    <Status 1>
                                  LED1 status: (0=OFF; 1=ON;
                           ххН
                                 2=BLINKING; 3=NO LED MODE)
    <Status 2>
                           ххH
                                  LED2 status: (0=OFF: 1=ON:
                                  2=BLINKING; 3=NO LED MODE)
    <LRC>
                           ххН
```

The UR5HCSPI will send the LED Status Report to the host when it receives the LED Status Request Command from the host.

Resend Request

```
<CONTROL> 80H
<RESEND> A5H
<LRC> 25H
```

The UR5HCSPI will send this Resend Request Command to the host when its command buffer is full, or if it detects either a parity error or an unknown command during a system command transmission.



COMMANDS FROM THE HOST TO THE UR5HCSPI

Commands from the Host - Summary					
Command Name	Code	Description			
Initialize	AOH	Causes the UR5HCSPI to enter the power-on state			
Initialization Complete	A1H	Issued as a response to the "Initialize Request"			
Heartbeat Request	A2H	The UR5HCSPI will respond with "Heartbeat Response"			
Identification Request	F2H	The UR5HCSPI will respond with "Identification Response"			
LED Status Request	A3H	The UR5HCSPI will respond with "LED Status Response"			
LED Modify	A6H	The UR5HCSPI will change the LED accordingly			
Resend Request	A5H	Issued upon error during the reception of a packet			
Input/Output Mode Modify	A7H	The UR5HCSPI will modify or report the status of the GIO0 pin			
Output Data to I/O pin	A8H	The UR5HCSPI will output a signal to the GIO0 pin			
Set Wake-Up Keys	<u>A9H</u>	Defines which keys are "wake-up" keys			

Each command to UR5HCSPI is composed of a sequence of codes. All commands start with <ESC> code (1BH) and end with the LRC code (bitwise exclusive OR of all bytes).

COMMANDS FROM THE HOST TO THE UR5HCSPI ANALYTICALLY

Initialize

<ESC> 1BH <INIT> A0H <LRC> 7BH

When the UR5HCSPI receives this command, it will clear all buffers and return to the power-on state.

Initialization Complete

<ESC> 1BH <INIT COMPLETE> A1H <LRC> 7AH

When the UR5HCSPI receives this command, it will enable transmission of keyboard data. Keyboard data transmission is disabled if the TX output buffer is full (32 bytes). Note that if the transmit data buffer gets full the encoder will issue an "Initialize Request" to the host.

Heartbeat Request

<ESC> 1BH <ONLINE> A2H <LRC> 79H

When the UR5HCSPI receives this command, it will reply with the Heartbeat Response Report.

Identification Request

<ESC> 1BH <ID> F2H <LRC> 29H

The UR5HCSPI will reply to this command with the Identification Response Report.



COMMANDS FROM THE HOST TO THE UR5HCSPI, (CON'T)


Set Wake-Up Keys <esc> <setmatrix> <col0></col0></setmatrix></esc>	1BH A9H xxH (R7	LED Status Request <esc> <led> <lrc></lrc></led></esc>	1BH A3H 78H	
R6 R5 R4 R3 R2 R1 R	0 Bitmap: 0-	When UR5HCSPI receives this	comma	and, it will reply with the LED Status
enabled, 1-disabled)		Report.		
<col1></col1>	xxH			
<col2></col2>	xxH	LED Modify		
<col3></col3>	xxH	<esc></esc>	1BH	
<col4></col4>	xxH	<modled></modled>	A6H	
<col5></col5>	xxH	<led number=""></led>	xxH	LED number (0)
<col6></col6>	xxH	<led state=""></led>	xxH	(0=LED OFF; 1=LED ON; 2=LED
<col7></col7>	xxH	BLINKING)		
<col8></col8>	xxH	<on interval=""></on>	xxH	Time in 1/16ths of a second for
<col9></col9>	xxH	LED to be on		
<col10></col10>	xxH	<off interval=""></off>	xxH	Time in 1/16ths of a second for
<col11></col11>	xxH	LED to be off		
<switches></switches>	xxH	<meta count=""/>	xxH	Number of blinks after which to
<lrc></lrc>	xxH	apply meta blink interval		
		<meta interval=""/>	xxH	Time in 1/16ths of a second for
The "Set Wake-Up Key	s" command	LED to be off after <meta co<="" td=""/> <td>UNT> b</td> <td>links</td>	UNT> b	links
is used to disable spe	cific keys	<lrc></lrc>	xxH	

command, the host can set only a group of keys.

is used to disable specific keys < LRC> xxH
from waking up the host. Using this When the UR5HCSPI receives this command, it will change the LED mode accordingly.



SUGGESTED SCHEMATIC FOR THE UR5HCSPI-FB



www.semtech.com



IMPLEMENTATION NOTES FOR THE UR5HCSPI

The following notes pertain to the suggested schematic found on the previous page.

The Built-in Oscillator on the UR5HCSPI-06 requires the attachment of the 2.00 MHz Ceramic Resonators with built-in Load Capacitors.. You can use either an AVX, part number PBRC-2.00 BR; or a Murata part number CSTCC2.00MG ceramic resonator.

It may also be possible to operate with the 2.00 MHz Crystal, albeit with reduced performance. Due to their high Q, the Crystal oscillator circuits start-up slowly. Since the SPICoder™ constantly switches the clock on and off, it is important that the Ceramic Resonator is used (it starts up much quicker than the Crystal). Resonators are also less expensive than Crystals.

Also, if Crystal is attached, two Load Capacitors (33pF to 47pF) should be added, a Capacitor between each side of the Crystal and ground.

In both cases, using Ceramic Resonator with built-in Load Capacitors, or Crystal with external Load Capacitors, a feedback Resistor of 1 Meg should be connected between OSCIN and OSCOUT.

Troubleshoot the circuit by looking at the Output pin of the Oscillator. If the voltage is half-way between Supply and Ground (while the Oscillator should be running) --- the problem is with the Load Caps / Crystal. If the voltage is all the way at Supply or Ground (while the Oscillator should be running) --- there are shorts on the PCB.

Note: When the Oscillator is intentionally turned OFF, the voltage on the Output pin of the Oscillator is High (at the Supply rail).



VS					
Symbol			Value		Unit
Vdd		-0.3 to +7.0		V	
Vin	 ! 			d +0.3	V
T			25		mA
Ta			T low to T high		° C
			-40 to +85		
Tstg -			-65 to +150		°C
Symbol			Value		Unit
Tja					°C per W
			60		•
			70		
Vdd=3.3 Vdc +/-1	10%, Vss=0 V	dc, Tempe	erature range=T le	ow to T high unless	otherwise noted)
	Min			Max	Unit
Vol				0.1	V
Voh	Vdd-0.1	1			
Voh	Vdd-0.8				V
Vol:			-	0.4	V
Vih	0.7xVdc			Vdd	V
Vil	Vss			0.2xVdd	V
Ipp			5	10	mA
Vrm	2.0				V
Idd			1.53	3.0	mA
			0.711		mA
			2.0	20	μΑ
lil				+/-10	μA
lin			•		μA
Cio			8	12	pF
00/ 1/00 0 1/-1 :	Taman av - t				
0%, VSS=0 Vac, Symbol	iemperature r	range=110 Min	w to I nigh unles	<u>SS otnerwise noted)</u> Max	Unit
fosc					MHz
				2.0	
		dc		2.0	
- tcvc		1000			ns
				100	ms
				_	ms
		8			tcyc
41.7					
tlih		250			115
tlih tilil		<u>250</u>		<u> </u>	ns tcyc
	Symbol Vdd Vin I Ta Tstg - Symbol Tja Symbol Vol Voh Voh Voh Voh Vil Ipp Vrm Idd Iii Iin Cio O%, Vss=0 Vdc, Symbol fosc tcyc toxov tilch trl	Symbol Vdd Vin I Ta Tstg - Symbol Tja Vdd=3.3 Vdc +/-10%, Vss=0 V Symbol Vol Voh Voh Vdd-0.8 Vol: Vih Vih Vil Vss Ipp Vrm Idd Iii Iiin Cio O%, Vss=0 Vdc, Temperature I Symbol fosc tcyc toxov tilch trl	Symbol Vdd Vin	Symbol Value	Symbol Value Void Void

^{*}The minimum period tlil should not be less than the number of cycle times it takes to execute the interrupt service routine plus 21 tcyc.



SPICODER™ BILL OF MATERIALS

UR5HCSPI-FB

Quantity	Manufacturer	Part#	Description
3	Generic	_330 Ohms	330 Ohms Resistor
3	Generic	LED	Led used as LED1. LED2. LED3
3	Generic	15 K	15 K Resistors
1	Generic	150 K	150 K Resistors
1	Generic	1M	1M Resistors
2	Generic	1.5 K	1.5 K Resistors
1	TELCOM	TC54VC4302ECB713	IC Volt Detector CMOS 4.3V SOT23, for 5V Operation
		TC54VC2702ECB713	IC Volt Detector CMOS 2.7V SOT23, for 3.3V Operation
1	AVX	PBRC-2.00BR	2.00MHZCeramic Resonator with Built in Capacitors, SMT
			<u> </u>

Revised 7/14/99



This Page Left Intentionally Blank



For sales information and product literature, contact:

HID & System Mgmt Division Semtech Corporation 568 Broadway New York, NY 10012 hidinfo@semtech.com http://www.semtech.com 212 226 2042 Telephone 212 226 3215 Telefax

Semtech Western Regional Sales 805-498-2111 Telephone 805-498-3804 Telefax

Semtech Central Regional Sales 972-437-0380 Telephone 972-437-0381 Telefax

Semtech Eastern Regional Sales 203-964-1766 Telephone 203-964-1755 Telefax

Semtech Asia-Pacific Sales Office +886-2-2748-3380 Telephone +886-2-2748-3390 Telefax

Semtech Japan Sales Office +81-45-948-5925 Telephone +81-45-948-5930 Telefax

Semtech Korea Sales Sales +82-2-527-4377 Telephone +82-2-527-4376 Telefax

Northern European Sales Office +44 (0)2380-769008 Telephone +44 (0)2380-768612 Telefax

Southern European Sales Office +33 (0)1 69-28-22-00 Telephone +33 (0)1 69-28-12-98 Telefax

Central European Sales Office +49 (0)8161 140 123 Telephone +49 (0)8161 140 124 Telefax

Copyright 2000-2001 Semtech Corporation. All rights reserved. Zero-Power, SPICoder and Self-Power Management are trademarks of Semtech Corporation. Semtech is a registered trademark of Semtech Company. All other trademarks belong to their respective companies.

INTELLECTUAL PROPERTY DISCLAIMER

This specification is provided "as is" with no warranties whatsoever including any warranty of merchantability, fitness for any particular purpose, or any warranty otherwise arising out of any proposal, specification or sample. A license is hereby granted to reproduce and distribute this specification for internal use only. No other license, expressed or implied to any other intellectual property rights is granted or intended hereby. Authors of this specification disclaim any liability, including liability for infringement of proprietary rights, relating to the implementation of information in this specification. Authors of this specification also do not warrant or represent that such implementation(s) will not infringe such rights.