

Vishay Telefunken

Universal LED in ø 5 mm Tinted Diffused Package

Color	Туре	Technology	Angle of Half Intensity $\pm \phi$
Red	TLUR54/TLUR64	GaAsP on GaAs	30°

Features

- For DC and pulse operation
- Luminous intensity categorized
- Standard ø 5 mm (T-1³/₄) package
- TLUR54.. with stand-offs
- TLUR64.. without stand-offs



Applications

General indicating and lighting purposes

Absolute Maximum Ratings

 $T_{amb} = 25^{\circ}C$, unless otherwise specified **TLUR54../TLUR64..**

Parameter	Test Conditions	Symbol	Value	Unit	
Reverse voltage		V _R	6	V	
DC forward current		١ _F	50	mA	
Surge forward current	t _p ≤ 10 μs	I _{FSM}	1	А	
Power dissipation	$T_{amb} \le 65^{\circ}C$	P _V	100	mW	
Junction temperature		Τ _i	100	°C	
Storage temperature range		T _{stg}	-55 to +100	°C	
Soldering temperature	$t \le 5$ s, 2 mm from body	T _{sd}	260	°C	
Thermal resistance junction/ambient		R _{thJA}	350	K/W	

Vishay Telefunken



Optical and Electrical Characteristics

 $T_{amb} = 25^{\circ}C$, unless otherwise specified **Red** (**TLUR54../TLUR64..**)

Parameter	Test Conditions	Туре	Symbol	Min	Тур	Max	Unit
Luminous intensity	I _F = 10 mA,	TLUR5400/6400	IV	0.4	0.8		mcd
	$I_{Vmin}/I_{Vmax} \ge 0.5$	TLUR5401/6401	IV	1	2.5	5	mcd
Dominant wavelength	I _F = 10 mA		λ _d		645		nm
Peak wavelength	I _F = 10 mA		λρ		660		nm
Angle of half intensity	I _F = 10 mA		φ		±30		deg
Forward voltage	I _F = 20 mA		VF		1.6	2	V
Reverse voltage	I _R = 10 μA		V _R	6	15		V
Junction capacitance	V _R = 0, f = 1 MHz		Cj		50		рF

Typical Characteristics ($T_{amb} = 25^{\circ}C$, unless otherwise specified)



Figure 1 Power Dissipation vs. Ambient Temperature















TLUR54../64..

Vishay Telefunken



Figure 5 Forward Current vs. Forward Voltage



Figure 6 Rel. Luminous Intensity vs.Ambient Temperature





Figure 8 Relative Luminous Intensity vs. Forward Current



Figure 9 Relative Luminous Intensity vs. Wavelength

TLUR54../64..

Vishay Telefunken



Dimensions in mm





TLUR54../64..

Vishay Telefunken



Ozone Depleting Substances Policy Statement

It is the policy of Vishay Semiconductor GmbH to

1. Meet all present and future national and international statutory requirements.

2. Regularly and continuously improve the performance of our products, processes, distribution and operating systems with respect to their impact on the health and safety of our employees and the public, as well as their impact on the environment.

It is particular concern to control or eliminate releases of those substances into the atmosphere which are known as ozone depleting substances (ODSs).

The Montreal Protocol (1987) and its London Amendments (1990) intend to severely restrict the use of ODSs and forbid their use within the next ten years. Various national and international initiatives are pressing for an earlier ban on these substances.

Vishay Semiconductor GmbH has been able to use its policy of continuous improvements to eliminate the use of ODSs listed in the following documents.

- 1. Annex A, B and list of transitional substances of the Montreal Protocol and the London Amendments respectively
- 2. Class I and II ozone depleting substances in the Clean Air Act Amendments of 1990 by the Environmental Protection Agency (EPA) in the USA
- 3. Council Decision 88/540/EEC and 91/690/EEC Annex A, B and C (transitional substances) respectively.

Vishay Semiconductor GmbH can certify that our semiconductors are not manufactured with ozone depleting substances and do not contain such substances.

We reserve the right to make changes to improve technical design and may do so without further notice.

Parameters can vary in different applications. All operating parameters must be validated for each customer application by the customer. Should the buyer use Vishay-Telefunken products for any unintended or unauthorized application, the buyer shall indemnify Vishay-Telefunken against all claims, costs, damages, and expenses, arising out of, directly or indirectly, any claim of personal damage, injury or death associated with such unintended or unauthorized use.

> Vishay Semiconductor GmbH, P.O.B. 3535, D-74025 Heilbronn, Germany Telephone: 49 (0)7131 67 2831, Fax number: 49 (0)7131 67 2423