MITSUBISHI (Dig./Ana. INTERFACE)

M51995P.FP

SWITCHING REGULATOR CONTROL

DESCRIPTION

M51995 is the primary switching regulator controller which is especially designed to get the regulated DC voltage from AC power supply.

This IC can directly drive the MOS-FET with fast rise and fast fall output pulse.

Type M51995 has the functions of not only high frequency OSC and fast output drive but also current limit with fast response and high sensibility so the true "fast switching regulator" can be realized.

It has another big feature of current protection to short and over current, owing to the integrated timer-type protection circuit, if few parts are added to the primary side.

The M51995 is equivalent to the M51977 with externally resettable OVP(over voltage protection)circuit.

FEATURES

- 500kHz operation to MOS FET
 - Output current · · · · · ±2A
 - · Output rise time 60ns, fall time 40ns
 - · Modified totempole output method with small through
- Compact and light-weight power supply
 - Small start-up current ······ 90µA typ.
 - · Big difference between "start-up voltage" and "stop voltage" makes the smoothing capacitor of the power input section small.
 - Start-up threshold 16V, stop voltage 10V
 - · Packages with high power dissipation are used to withstand the heat generated by the gate-drive current of MOS FET.
 - 16-pin DIP, 20-pin SOP 1.5W (at 25°C)
- Simplified peripheral circuit with protection circuit and built-in large-capacity totempole output
 - · High-speed current limiting circuit using pulse-bypulse method (Two systems of CLM+pin, CLM-pin)
 - · Protection by intermittent operation of output over current Timer protection circuit
 - · Over-voltage protection circuit with an externally resettable latch (OVP)
 - · Protection circuit for output miss action at low supply voltage (UVLO)
- High-performance and highly functional power supply
 - · Triangular wave oscillator for easy dead time setting


APPLICATION

Feed foward regulator, fly-back regulator


RECOMMENDED OPERATING CONDITIONS

Supply voltage range ------12~36V Operating frequency·····less than 500kHz Oscillator frequency setting resistance

•	T-ON pin resistance Ron	10k∼75kΩ
	T_OFF nin registance Rass	· 2k~30kΩ







ABSOLUTE MAXIMUM RATINGS

Symbol	Parameter	Conditions	Ratings	Unit	
Vcc	Supply voltage		36	V	
Vc	Collector voltage		36	V	
		Peak	±2	Α	
lo	Output current	Continuous	±0.15		
V _{VF}	VF terminal voltage		Vcc	V	
V _{ON/OFF}	ON/OFF terminal voltage		Vcc	V	
V _{CLM} -	CLM-terminal voltage		-4.0~+4.0	V	
V _{CLM+}	CLM-terminal voltage		-0.3~+4.0	V	
I _{OVP}	OVP terminal current		8	mA	
VDET	DET terminal voltage		6	V	
IDET	DET terminal input current		5	mA	
V _{FB}	F/B terminal voltage		0~10	V	
ITON	T-ON terminal input current		-1	mA	
I _{TOFF}	T-OFF terminal input current		-2	mA	
Pd	Power dissipation	Ta=25°C	1.5	W	
Kθ	Thermal derating factor	Ta>25℃	12	mW/°C	
Topr	Operating temperature		-30~+85	Ĉ	
Tstg	Storage temperature		-40~+125	r	
Ti	Junction temperature		150	ా	

Note 1. "+" sign shows the direction of current flow into the IC and "-" sign shows the current flow from the IC

- This terminal has the constant voltage characteristic of 6~8V, when current is supplied from outside The maximum allowable voltage is 6V when the constant voltage is applied to this terminal. And maximum allowable current into this terminal is 5mA
- 3. The low impedance voltage supply should not be applied to the OVP terminal




ELECTRICAL CHARACTERISTICS (V_{cc}=18V, T_a=25°C, unless otherwise noted)

Dist.	Symbol	_		Limits			Unit
Block		Parameter	Test conditions	Min	Тур	Max	Unit
	Vcc	Operating supply voltage range		V _{CC(STOP)}		35	V
	V _{CC(START)}	Operation start up voltage		15. 2	16. 2	17. 2	V
۱Ę	V _{CC(STOP)}	Operation stop voltage		9.0	9. 9	10.9	· ·
Supply voltage circuit current	△Vcc	Difference voltage between operation start and stop	AVCC=VCC(START) -VCC(STOP)	5.0	6.3	7. 6	V
2			V _{CC} =14.5V, T _a =25℃	50	90	140	μA
💆	CCL	Stand—by current	$V_{CC} = 14.5V, -30 \le T_a \le 85^{\circ}$	40	90	190	μA
l å	Icco	Operating circuit current	V _{oc} =30V	10	15	21	mA
\$		Circuit current in OFF state	V _{CC} =25V	0. 95	1. 31	5. 0	mA
<u>ā</u>	loc off		V _{cc} =14V	50	90	140	μА
<i>3</i>		Classit assess to these OFF state	V _{CC} =25V	0. 95	1.35	2. 0	mA
	Icc ct	Circuit current in timer OFF state	V _{CC} =14V	1	160	240	μA
			V _{cc} =25V	1.3	2.0	3. 0	mA
	ICC OVP	Circuit current in OVP state	V _{cc} =9.5V	125	200	310	μA
#	V _{THH} ON/OFF	ON/OFF terminal high threshold voltage		2. 1	2.6	3. 1	>
ON/OFF	V _{THL ON/OFF}			1.9	2.4	2.9	V
8	∆V _{THON/OFF}	ON/OFF terminal hysterisis voltage		0.1	0.2	0.3	٧
	IFBMIND	Current at 0% duty	F/B terminal input current	-2.1	-1.54	-1.0	mA
	IFBMAXO	Current at maximum duty	F/B terminal input current	-0.90	-0.55	-0.40	mA
l &	∆IFB	Current difference between max and 0% duty	△IFB=IFBMIND-IFBMAXD	-1.35	0.99	-0.70	mA
"	V _{FB}	Terminal voltage	F/B terminal input current=0.95mA	4.9	5.9	7. 1	٧
	R _{FB}	Terminal resistance		420	600	780	Ω
8	V _{DET}	Detection voltage		2.4	2.5	2.6	٧
Detection	INDET	Input current of detection amp	V _{DET} =2.5V	-	1.0	3.0	μA
Į	GAVDET	Voltage gain of detection amp		30	40	_	dB
	V _{THOVPH}	OVP terminal H threshold voltage		540	750	960	m۷
	4V _{THOVP}	OVP terminal hysterisis voltage	4VTHOVE=VTHOVEH-VTHOVEL		30		mV
	ITHOUP	OVP terminal threshold current		80	150	250	μΑ
	INOVE	OVP terminal input current	V _{OVP} =400mV	80	150	250	μΑ
8	VCCOVPC	OVP reset supply voltage		7.5	9.0	10.0	V
0	V _{CC(STOP)}	Difference supply voltage between operation	OVP terminal is open.				
	-V _{CCOVPC}	stop and OVP reset	(high impedance)	0.55	1.20	_	
	*CCOVPC	Current from OVP terminal	V _{CC} =30V	-480	-320	-213	
	I _{THOVPC}		V _{CC} =18V	-210	-140	-93	μA
 		Timer frequency	C _T =4.7μF	0. 27	0.40	0.60	Hz
	Timer frequency ITIMECH Timer charge current	rine reductor	V _{CT} =3.3V, T _a =-5°C	-193	-138	-102	<u></u>
<u> </u>		T _a = 25°C	-178	-127	-94	μA	
Ĕ			T _a = 85℃	-147	-105	-78	,
	TIME	OFF time/ON time ratio	'a	7.0	8. 7	11.0	
	TIME _{OFF/ON}	CLM—terminal threshold voltage	-5≤ T _a ≤ 85℃	-220	-200	-180	mV
<u> </u>	V _{THCLM} —	CLM—terminal current	V _{CLM} ==-0.1V	-170	-125	-90	μΑ
CLN	INCLM-	Delay time from CLM—to V _{OUT}	VOLM- VIII		170		ns
	T _{PDCLM} —		-5≤ Ta≤ 85℃	180	200	220	mV
l ±	V _{THCLM+}	CLM+terminal threshold voltage		-270	-205	-140	#A
CLM+	INCLM+	CLM+terminal current	V _{CLM+} =0V		130		ns
L	T _{PDCLM+}	Delay time from CLM + to V _{OUT}		I	1,50		110


ELECTRICAL CHARACTERISTICS (V_{cc}=18V, T_a=25°C, unless otherwise noted)(CONTINUE)

Block	Symbol	Parameter		Test conditions		Limits		
DIOCK	Symbol			Test conditions	Min	Тур	Max	Unit
	fosc	Oscillating frequency		$R_{ON}=20k\Omega$, $R_{OFF}=17k\Omega$ $C_F=220pF$, $-5 \le T_a \le 85^{\circ}C$	170	188	207	kHz
₫	T _{DUTY}	Maximum ON duty			47. 0	50.0	53.0	%
Oscillator	Vosch	Upper limit voltage of oscillation waveform		f _{osc} =188kHz	3. 97	4. 37	4. 77	V
ő	VoscL	Lower limit voltage of oscillation waveform		f _{OSC} =188kHz	1. 76	1.96	2. 16	
	⊿V _{osc}	Voltage difference between upper limit and lower limit of OSC waveform		f _{osc} =188kHz	2. 11	2. 41	2. 71	٧
	foscvr	OSC frequency in CLM	V _F =5∨	$R_{ON}=20k \Omega$, $R_{OFF}=17k\Omega$	170	188	207	iii kHz l
		operating state	V _F =2V	C _F =220pF	108	124	143	
, ,	TVFDUTY	Duty in CLM operating state	V _F =0.2V	Min off duty / Max on duty	11.0	13.7	22.0	
	V _{THTIME}	VF voltage at timer operating start			2. 7	3.0	3.3	٧
	Ive	VF terminal input current		Source current		2	6	μА
	V _{OL} 1	Output low voltage		V _{CC} =18V, I _O =10mA	_	0.05	0.4	V
	V _{OL 2}			V _{CC} =18V, I _O =100mA		0.7	1.4	V
	V _{OL 3}			V _{CC} =5V, I _O =1mA	_	0.69	1.0	٧
ž	V _{OL4}			V _{CC} =5V, I _O =100mA		1.3	2.0	· V
Output	V _{OH 1}	Output high voltage		V _{CC} =18V, I _O =-10mA	16.0	16. 5	_	V
	V _{OH 2}			V _{CC} =18V, I _C =-100mA	15.5	16.0	_	٧
	TRISE	Output voltage rise time		No load		50	_	ns
	T _{FALL}	Output voltage fall time		No load		35	_	ns

TYPICAL CHARACTERISTICS




CIRCUIT CURRENT VS. SUPPLY VOLTAGE (OVP OPERATION)




CIRCUIT CURRENT VS. SUPPLY VOLTAGE (TIMER OFF STATE)

SUPPLY VOLTAGE V_{CC} (V)




SUPPLY VOLTAGE Vcc (V)

CIRCUIT CURRENT VS. SUPPLY VOLTAGE (NORMAL OPERATION)




SUPPLY VOLTAGE V_{CC} (V)

CIRCUIT CURRENT VS. SUPPLY VOLTAGE (OFF STATE)




SUPPLY VOLTAGE Vcc (V)

OVP TERMINAL THRESHOLD VOLTAGE VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (C)

THRESHOLD VOLTAGE OF ON/OFF TERMINAL VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (C)

INPUT CURRENT OF VF TERMINAL VS. INPUT VOLTAGE




VF TERMINAL VOLTAGE VVF (V)

CHARGE CURRENT OF TIMER VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (°C)

THRESHOLD CURRENT OF ON/OFF TERMINAL VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (C)

DISCHARGE CURRENT OF TIMER VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (℃)

ON AND OFF DURATION OF TIMER VS. AMBIENT TEMPERATURE (INTERMITTENT OPERATION)




AMBIENT TEMPERATURE Ta (℃)


VF THRESHOLD VOLTAGE FOR TIMER VS. AMBIENT TEMPERATURE



THRESHOLD VOLTAGE OF CLM— TERMINAL VS. AMBIENT TEMPERATURE




CLM- TERMINAL CURRENT VS. CLM- TERMINAL VOLTAGE




CLM- TERMINAL VOLTAGE VCLM- (V)

THRESHOLD VOLTAGE OF CLM+ TERMINAL VS. AMBIENT TEMPERATURE




CLM+ TERMINAL CURRENT




CLM+ TERMINAL VOLTAGE VCLM+ (V)

OUTPUT HIGH VOLTAGE VS. OUTPUT SOURCE CURRENT




OUTPUT SOURCE CURRENT IOH (A)


OUTPUT LOW VOLTAGE VS. OUTPUT SINK CURRENT



INPUT CURRENT OF DETECTION AMP VS. AMBIENT TEMPERATURE




ON duty VS. F/B TERMINAL INPUT CURRENT




F/B TERMINAL INPUT CURRENT IF/B (mA)

DETECTION VOLTAGE VS. AMBIENT TEMPERATURE




DETECTION AMP VOLTAGE GAIN




FREQUENCY f (Hz)

ON duty VS. F/B TERMINAL INPUT CURRENT




F/B TERMINAL INPUT CURRENT IF/B (mA)

ON duty VS. F/B TERMINAL INPUT CURRENT




F/B TERMINAL INPUT CURRENT IF/B (mA)

OSCILLATING FREQUENCY VS. CF TERMINAL CAPACITY




CF TERMINAL CAPACITY (pF)

OSCILLATING FREQUENCY VS. AMBIENT TEMPERATURE




UPPER & LOWER LIMIT VOLTAGE OF OSC VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (℃)

ON duty VS. ROFF




OSCILLATING FREQUENCY VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (℃)






AMBIENT TEMPERATURE Ta (℃)

ON duty VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (℃)

INPUT VOLTAGE OF VF TERMINAL VS. EXPANSION RATE OF PERIOD




EXPANSION RATE OF PERIOD (TIMES)

ON duty VS. AMBIENT TEMPERATURE




AMBIENT TEMPERATURE Ta (℃)

INPUT VOLTAGE OF VF TERMINAL VS. EXPANSION RATE OF PERIOD




EXPANSION RATE OF PERIOD (TIMES)

OVP TERMINAL INPUT VOLTAGE VS. INPUT CURRENT



OVP TERMINAL INPUT VOLTAGE VOVP (V)



FUNCTION DESCRIPTION

Type M51995P and M51995FP are especially designed for off-line primary PWM control IC of switching mode power supply (SMPS) to get DC voltage from AC power supply Using this IC, smart SMPS can be realized with reasonable cost and compact size as the number of external electric

parts can be reduced and also parts can be replaced by reasonable one.

In the following circuit diagram, MOS-FET is used for output transistor, however bipolar transistor can be used with no problem





Fig. 1 Example application circuit diagram of feed forward regulator



Pin No is related with M51995P.

Fig. 2 Example application circuit diagram of fly-back regulator



Start-up circuit section

The start-up current is such low current level as typical 90μ A, as shown in Fig. 3, when the V_{CC} voltage is increased from low level to start-up voltage $V_{CC(START)}$.

In this voltage range, only a few parts in this IC, which has the function to make the output voltage low level, is alive and $I_{\rm CC}$ current is used to keep output low level. The large voltage difference between $V_{\rm CC}$ (START) and $V_{\rm CC}$ (STOP) makes start-up easy, because it takes rather long duration from $V_{\rm CC}$ (START) to $V_{\rm CC}$ (STOP).




Fig. 3 Circuit current vs. supply voltage

Oscillator section

The oscillation waveform is the triangle one. The ONduration of output pulse depends on the rising duration of the triangle waveform and dead-time is decided by the falling duration.

The rising duration is determined by the product of external resistor R_{ON} and capacitor C_F and the falling duration is mainly determined by the product of resistor R_{OFF} and capacitor C_F .

(1)Oscillator operation when intermittent action and OSC control circuit does not operate

Fig. 4 shows the equivalent charging and discharging circuit diagram of oscillator when the current limitting circuit does not operate. It means that intermittent action and OSC control circuit does not operate.

The current flows through R_{ON} from the constant voltage source of 5.8V. C_{F} is charged up by the same amplitude as R_{ON} current, when internal switch SW_1 is switched to "charging side". The rise rate of CF terminal is given as

where V_{T-ON}≃4.5V

The maximum on duration is approximately given as

$$\simeq \frac{(V_{OSCH} - V_{OSCL}) \times R_{ON} \times C_F}{V_{T-ON}} \quad (s) \quad \cdots \quad (2)$$

where
$$V_{OSCH} \simeq 4.4V$$

 $V_{OSCL} \simeq 2.0V$

 C_F is discharged by the summed-up of R_{OFF} current and one sixteenth (1/16) of R_{ON} current by the function of Q_2 , Q_3 and Q_4 when SW_1 , SW_2 are switched to "discharge side".




Fig. 4 Schematic diagram of charging and discharging control circuit for OSC, capacitor C_F




Fig. 5 OSC. waveform at normal condition (no-operation of intermittent action and OSC. control circuit)

So fall rate of CF terminal is given as

$$\simeq \frac{V_{\text{T-OFF}}}{R_{\text{OFF}} \times C_F} + \frac{V_{\text{T-ON}}}{16 \times R_{\text{ON}} \times C_F} \quad \text{(V/s)} \cdot \dots \cdot (3)$$

The minimum off duration approximately is given as

$$\simeq \frac{(V_{OSCH} - V_{OSCL})XC_F}{\frac{V_{T-OFF}}{R_{OFF}} + \frac{V_{T-ON}}{16 \times R_{ON}}}$$
 (s)(4)

where V_{T-OFF}≃3.5V

The cycle time of oscillation is given by the summation of Equations 2 and 4.

The frequency including the dead-time is not influenced by the temperature because of the built-in temperature compensating circuit.

(2)Oscillator operation when intermittent action and OSC control circuit operates.

When over current signal is applied to CLM+ or CLM— terminal, and the current limitting circuit, intermittent action and OSC control circuit starts to operate. In this case T-OFF terminal voltage depends on VF terminal voltage, so the oscillation frequency decreases and dead-time spreads.

The rise rate of oscillation waveform is given as

$$\simeq \frac{V_{T-ON}}{R_{ON} \times C_F} \quad (V/s) \quad (5)$$

The fall rate of oscillation waveform is given as

$$\simeq \frac{V_{VF} - V_{VFO}}{R_{OFF} \times C_F} + \frac{V_{T-ON}}{16 \times R_{ON} \times C_F} \quad (V/s) \cdot \cdots \cdot (6)$$

where V_{T-ON}≃4.5V

V_{VF}: VF terminal voltage

V_{VEO}≃ 0.4V

$$V_{VF}-V_{FO}=0$$
 if $V_{VF}-V_{VFO}<0$

$$V_{VF} - V_{VFO} = V_{T-OFF}$$
 if $V_{VF} - V_{VFO} > V_{T-OFF} \approx 3.5V$

So when $V_{VF} > 3.5V$, the operation is just same as that in the no current limitting operation state.

The maximum on-duration is just same as that in the nooperation state of intermittent and oscillation control circuit and is given as follows;

$$\simeq \frac{(V_{OSCH} - V_{OSCL}) \times R_{ON} \times C_F}{V_{T-ON}} \quad (s) \qquad (7)$$

The minimum off-duration is approximately given as;

$$\simeq \frac{(V_{OSCH} - V_{OSCL}) \times C_F}{\frac{V_{VF} - V_{VFO}}{R_{OFF} \times C_F}} + \frac{V_{T-ON}}{16 \times R_{ON} \times C_F}$$
(8)

The oscillation period is given by the summation of Equation (7) and (8).

As shown in Fig. 7, the internal circuit kills the first output pulse in the output waveform. The output waveform will appear from the second pulse cycle because the duration of first cycle takes C_{F} charging time longer comparing with that at the stable operating state.

Usually the applied voltage to VF terminal must be proportional the output voltage of the regulator.

So when the over current occurs and the output voltage of the regulator becomes low, the off-duration becomes wide. There are two methods to get the control voltage, which depends on the output voltage, on primary side. For the fly back type regulator application, the induced voltage on the third or bias winding is dependent on output voltage. On the other hand, for the feed forward type regulator application, it can be used that the output voltage depends on the product of induced voltage and "on-duty", as the current of




Fig. 6 OSC. waveform with operation of intermittent and OSC. control circuit operation




Fig. 7 Relation between OSC. and output waveform circuit operation at start up




Fig. 8 Feedback loop with low pass filter from output to VF terminal

choke coil will continue at over load condition, it means the "continuous current" condition.

Fig. 8 shows one of the examples for VF terminal application for the feed forward type regulator.



PWM comparator and PWM latch section

Fig. 9 shows the PWM comparator and latch section. The on-duration of output waveform coincides with the rising duration of CF terminal waveform, when the infinitive resistor is connected between F/B terminal and GND.

When the F/B terminal has finite impedance and current flows out from F/B terminal, "A" point potential shown in Fig. 9 depends on this current. So the "A" point potential is close to GND level when the flow-out current becomes large.

"A" point potential is compared with the CF terminal oscillator waveform and PWM comparator, and the latch circuit is set when the potential of oscillator waveform is higher than "A" point potential.

On the other hand, this latch circuit is reset by high level signal during the deadtime of oscillation (falling duration of oscillation waveform). So the "B" point potential or output waveform of latch circuit is the one shown in Fig. 10.

The final output waveform or "C" point potential is got by combining the "B" point signal and dead-time signal logically. (please refer to Fig. 10)




Fig. 9 PWM comparator and latch circuit




Fig. 10 Waveforms of PWM comparator input point A, latch circuit points B and C

Current limitting section

When the current-limit signal is applied before the crossing instant of "A" point potential and CF terminal voltage shown in Fig. 9, this signal makes the output "off" and the off state will continue until next cycle. Fig. 11 shows the timing relation among them.

The current limitting circuit has two input terminals, one has the detector-sensitivity of +200mV to the GND terminal and the other has -200mV. The circuit will be latched if the input signal is over the limit of either terminal.

If the current limitting circuit is set, no waveform is generated at output terminal however this state is reset during the succeeding dead-time.

So this current limitting circuit is able to have the function in every cycle, and is named "pulse-by-pulse current limit".




Fig. 11 Operating waveforms of current limitting circuit

It is rather recommended to use not "CLM+" but "C4M+8m" terminal, as the influence from the gala office current of MOS-FET can be eliminated and wide voltage rating of +

4V to -4V is guaranteed for absolute maximum rating.

There happen some noise voltage on R_{CLM} during the switching of power transistor due to the snubber circuit and stray capacitor of the transformer windings.

To eliminate the abnormal operation by the noise voltage, the low pass fillter, which consists of R_{NF} and C_{NF} is used as shown in Fig. 12.

It is recommended to use $10{\sim}100\,\Omega$ for R_{NF} because such range of R_{NF} is not influenced by the flow-out current of some $200\mu\text{A}$ from CLM terminal and C_{NF} is designed to have the enough value to absorb the noise voltage.





Fig. 12 How to connect current limit circuit

Intermittent action and oscillation control section

When the internal current limitting circuit starts to operate and also the VF level decreases to lower than the certain level of some 3V, the dead-time spreads and intermittent action and OSC control circuit (which is one of the timer-type-protection circuit) starts to operate.

The intermittent action and OSC control circuit is the one to generate the control signal for oscillator and intermittent action circuit.

Fig.13 shows the timing-chart of this circuit. When the output of intermittent action and oscillation control is at "high" level, the waveform of oscillator depends on the VF terminal voltage and the intermittent action circuit begins to operate.



(a) With current limit signal




Fig. 13 Timing chart of interrmittent and OSC. control circuit

Intermittent action circuit section

Intermittent action circuit will start to operate when the output signal from the intermittent action and oscillation control circuit are "high" and also VF terminal voltage is lower than V_{THTIME} of about 3V.

Fig. 14 shows the block diagram of intermittent action circuit. Transistor Q is on state when VF terminal voltage is higher than V_{THTIME} of about 3V, so the CT terminal voltage is near to GND potential.

When VF terminal voltage is lower than V_{THTIME} , Q becomes "off" and the CT has the possibility to be charged up.

Under this condition, if the intermittent action and oscillation control signal become "high", the switch SW_A will close only in this "high" duration and C_T is charged up by the current of $120\mu A$ through SW_A (SW_B is open) and CT terminal potential will rise. The output pulse can be generated only in this duration.

When the CT terminal voltage reaches to 8V, the control logic circuit makes the SW_A "off" and SW_B "on", in order to flow in the $I_{TIMEOFF}$ of 15 μ A to CT terminal.

The IC operation will be ceased in the falling duration.

On the other hand, when CT terminal voltage decreses to lower than 2V, the IC operation will be reset to original state, as the control logic circuit makes the SW_A "on" and SW_B "off".

Therefore the parts in power circuit including secondary rectifier diodes are protected from the overheat by the over current.




Fig. 14 Block diagram of Intermitted action circuit




Fig. 15 Waveform of CT terminal

Fig. 16 shows the I_{CC} versus V_{CC} in this timer-off duration. In this duration the power is not supplied to IC from the third winding of transformer but through from the resistor R_1 connected to V_{CC} line.

If the R_1 shown in Fig. 1 and 2 is selected adequate value, V_{CC} terminal voltage will be kept at not so high or low but adequate value, as the I_{CC} versus V_{CC} characteristics has such the one shown in Fig. 16.




Fig. 16 I_{CC} vs. V_{CC} in timer-off duration of intermittent action circuit

To ground the CT terminal is recommended, when the intermittent mode is not used.

In this case the oscillated frequency will become low but the IC will neither stop the oscillation nor change to the intermittent action mode, when the current limit function becomes to operate and the VF terminal voltage becomes low.

Voltage detector circuit (DET) section

The DET terminal can be used to control the output voltage which is determined by the winding ratio of fly back transformer in fly-back system or in case of common ground cir-

cuit of primary and secondary in feed forward system.

The circuit diagram is quite similar to that of shunt regulator type 431 as shown in Fig. 17. As well known from Fig. 17 and Fig. 18, the output of OP AMP has the current-sink ability, when the DET terminal voltage is higher than 2.5V but it becomes high impedance state when lower than 2.5V DET terminal and F/B terminal have inverting phase characteristics each other, so it is recommended to connect the resistor and capacitor in series between them for phase compensation. It is very important, one can not connect by resistor directly as there is the voltage difference between them and the capacitor has the DC stopper function.




Fig. 17 Equivalent circuit diagram of voltage detector




Fig. 18 Equivalent circuit diagram of voltage detector

ON-OFF circuit section

Fig. 19 shows the circuit diagram of ON-OFF circuit. The current flown into the ON/OFF terminal makes the Q_4 "on" and the switching operation stop. On the other hand, the switching operation will recover as no current flown into ON/OFF terminal makes Q_4 "off". As the constant current source connected to Q_4 base terminal has support the hyster-

isis characteristics of $20\mu A$ at operation and $3\mu A$ at stopping. So the unstable operation is not appeared even if the ON/OFF terminal voltage signal varies slowly.

Fig. 20 shows how to connect the ON/OFF terminal. The switching operation will stop by switch-off and operate by switch-on.

Transistor or photo transistor can be replaced by this switch, of cource. No resistor of $30 \sim 100 \mathrm{k}\,\Omega$ is connected and ON/OFF terminal is directly connected to GND, when it is not necessary to use the ON/OFF operation.

Fig. 21 shows the I_{CC} versus V_{CC} characteristics in OFF state and V_{CC} will be kept at not so high or low but at the adequate voltage, when R_1 shown in Fig. 1 and 2 is selected properly.




Fig. 19 ON/OFF circuit




Fig. 20 Connecting of ON/OFF terminal




Fig. 21 I_{CC} vs. V_{CC} in OFF state

OVP circuit (over voltage protection circuit) section

OVP circuit is basically positive feedback circuit constructed by Q_2 , Q_3 as shown in Fig. 22.

 Q_2 , Q_3 turn on and the circuit operation of IC stops, when the input signal is applied to OVP terminal (threshold voltage $\simeq 750 mV$)

The current value of I₂ is about $150\mu A$ when the OVP does not operates but it decreases to about $2\mu A$ when OVP operates.

It is necessary to input the sufficient larger current (800 μ A ~8mA) than I₂ for triggering the OVP operation

The reason to decrease I_2 is that it is necessary that I_{CC} at the OVP rest supply voltage is small.

It is necessary that OVP state holds by circuit current from R_1 in the application example, so this IC has the characteristic of small $I_{\rm CC}$ at the OVP reset supply voltage (\simeq stand-by current + 20 μ A)

On the other hand, the circuit current is large in the higher supply voltage, so the supply voltage of this IC doesn't become so high by the voltage drop across R₁.

This characteristic is shown in Fig. 23.

The OVP terminal input current in the voltage lower than the OVP threshold voltage is based on I_2 and the input current in the voltage higher than the OVP threshold voltage is the sum of the current flowing to the base of Q_3 and the current flowing from the collector of Q_2 to the base.

For holding in the latch state, it is necessary that the OVP terminal voltage is kept in the voltage higher than V_{BE} of Q_3 .

So if the capacitor is connected between the OVP terminal and GND, even though \mathbf{Q}_2 turns on in a moment by the surge voltage, etc, this latch action does not hold if the OVP terminal voltage does not become higher than V_{BE} of \mathbf{Q}_3 by charging this capacitor.

For resetting OVP state, it is necessary to make the OVP terminal voltage lower than the OVP L threshold voltage or make $V_{\rm CC}$ lower than the OVP reset supply voltage.

As the OVP reset voltage is settled on the rather high voltage of 9.0V, SMPS can be reset in rather short time from the switch-off of the AC power source if the smoothing capacitor is not so large value.






Fig. 22 Detail diagram of OVP circuit




Fig. 23 CIRCUIT CURRENT VS SUPPLY VOLTAGE
(OVP OPERATION)

Output section

It is required that the output circuit have the high sink and source abilities for MOS-FET drive. It is well known that the "totempole circuit has high sink and source ability. However, it has the demerit of high through current.

For example, the through current may reach such the high current level of 1A, if type M51995 has the "conventional" totempole circuit. For the high frequency application such as higher than 100kHz, this through current is very important factor and will cause not only the large I_{CC} current and the inevitable heat-up of IC but also the noise voltage.

This IC uses the improved totempole circuit, so without deteriorating the characteristic of operating speed, its through current is approximately 100mA.

APPLICATION NOTE OF TYPE M51995P, FP Design of start-up circuit and the power supply of IC

(1)The start-up circuit when it is not necessary to set the start and stop input voltage

Fig. 24 shows one of the example circuit diagram of the start-up circuit which is used when it is not necessary to set the start and stop voltage.

It is recommended that the current more than $300\mu A$ flows through R₁ in order to overcome the operation start-up current $I_{CC(START)}$ and C_{VCC} is in the range of 10 to $47\mu F$. The product of R₁ by C_{VCC} causes the time delay of operation, so the response time will be long if the product is too much large.




Fig. 24 Start-up circuit diagram when it is not necessary to set the start and stop input voltage

Just after the start-up, the I_{CC} current is supplied from C_{VCC} , however, under the steady state condition, IC will be supplied from the third winding or bias winding of transformer, the winding ratio of the third winding must be designed so that the induced voltage may be higher than the operation-stop voltage $V_{CC(STOP)}$ Data Sheet at the IV cc voltage is recommended to be 12V to 17V as the

normal and optimum gate voltage is 10 to 15V and the output voltage ($V_{\rm CH}$) of type M51995P, FP is about ($V_{\rm CC}-2V$). It is not necessary that the induced voltage is settled higher than the operation start-up voltage $V_{\rm CC\,(START)}$, and the high gate drive voltage causes high gate dissipation, on the other hand, too low gate drive voltage does not make the MOS-FET fully on-state or the saturation state.




Fig. 25 Start-up circuit diagram when it is necessary to set the start and stop input voltage

(2)The start-up circuit when it is necessary to set the start and stop input voltage

It is recommend to use the third winding of "forward winding" or "positive polarity" as shown in Fig. 25, when the DC source voltages at both the IC operation start and stop must be settled at the specified values.

The input voltage $(V_{\text{IN} (START)})$, at which the IC operation starts, is decided by R_1 and R_2 utilizing the low start-up current characterisitics of type M51995P, FP.

The input voltage $(V_{\text{IN}\,(\text{STOP})})$, at which the IC operation stops, is decided by the ratio of third winding of transformer.

The $V_{\text{IN}\,(\text{START})}$ and $V_{\text{IN}\,(\text{STOP})}$ are given by following equations

where

 I_{CCL} is the operation start-up current of IC $V_{CC(START)}$ is the operation start-up voltage of IC $V_{CC(STOP)}$ is the operation stop voltage of IC V_F is the forward voltage of rectifier diode V'_{IN} (P-P) is the peak to peak ripple voltage of V_{CC} terminal $\simeq \frac{N_B}{N_P} V_{IN}$ RIP(P-P)

It is required that the $V_{\text{IN}\,(\text{START})}$ must be higher than $V_{\text{IN}\,(\text{STOP})}$.

When the third winding is the "fly back winding" or "reverse

polarity", the $V_{\text{IN}(START)}$ can be fixed, however, $V_{\text{IN}(STOP)}$ can not be settled by this system, so the auxiliary circuit is required.

(3)Notice to the V_{CC}, V_{CC} line and GND line

To avoid the abnormal IC operation, it is recommended to design the V_{CC} is not vary abruptly and has few spike voltage, which is induced from the stray capacity between the winding of main transformer.

To reduce the spike voltage, the C_{VCC} , which is connected between V_{CC} and ground, must have the good high frequency characteristics.

To design the conductor-pattern on PC board, following cautions must be considered as shown in Fig. 26.

- (a) To separate the emitter line of type M51995 from the the GND line of the IC
- (b) To locate the C_{VCC} as near as possible to type M51995 and connect directly
- (c) To separate the collector line of type M51995 from the V_{CC} line of the IC
- (d) To connect the ground terminals of peripheral parts of ICs to GND of type M51995 as short as possible




Fig. 26 How to design the conductor-pattern of type M51995 on PC board (schematic example)

(4)Power supply circuit for easy start-up

When IC start to operate, the voltage of the $C_{\rm VCC}$ begins to decrease till the $C_{\rm VCC}$ becomes to be charged from the third winding of main-transformer as the $I_{\rm CC}$ of the IC increases abruptly. In case shown in Fig. 24 and 25, some "unstable start-up" or "fail to start-up" may happen, as the charging interval of $C_{\rm VCC}$ is very short duration; that is the charging does occur only the duration while the induced winding voltage is higher than the $C_{\rm VCC}$ voltage, if the induced winding voltage is nearly equal to the "operation-stop voltage" of type M51995.

It is recommended to use the 10 to $47\mu F$ for C_{VCC1} , and about 5 times capacity bigger than C_{VCC1} for C_{VCC2} in Fig. 27.






Fig. 27 DC source circuit for stable start-up

OVP circuit

(1)To avoid the miss operation of OVP

It is recommended to connect the capacitor between OVP terminal and GND for avoiding the miss operation by the spike noise.

The OVP terminal is connected with the sink current source (\simeq 150 μ A)in IC when OVP does not operate, for absorbing the leak current of the photo coupler in the application.

So the resistance between the OVP terminal and GND for leak-cut is not necessary.

If the resistance is connected, the supply current at the OVP reset supply voltage becomes large.

As the result, the OVP reset supply voltage may become higher than the operation stop voltage.

In that case, the OVP action is reset when the OVP is triggered at the supply voltage a little high than the operation stop voltage.

So it should be avoided absolutely to connect the resistance between the OVP terminal and GND.




Fig. 28 Peripheral circuit of OVP terminal




Fig. 29 Example circuit diagram to make the OVP-reset-time fast




Fig. 30 OVP setting method using the induced third winding voltage on fly back system

(2)Application circuit to make the OVP-reset time fast

The reset time may becomes problem when the discharge time constant of $C_{FIN} \cdot (R_1 + R_2)$ is long. Under such the circuit condition, it is recommended to discharge the C_{VCC} forcedly and to make the V_{CC} low value. This makes the OVP-reset time fast.

(3)OVP setting method using the induced third winding voltage on fly back system

For the over voltage protection (OVP), the induced fly back type third winding voltage can be utilized, as the induced third winding voltage depends on the output voltage. Fig. 30 shows one of the example circuit diagram.

Current limitting circuit

(1)Peripheral circuit of CLM+, CLM- terminal

Fig.31 and 32 show the example circuit diagrams around the CLM+ and CLM- terminal. It is required to connect the low pass filter, in oder to reduce the spike current component, as the main current or drain current contains the spike current especially during the turn-on duration of MOS-FET.

1,000pF to 22,000pF is recommended for C_{NF} and the R_{NF1} and R_{NF2} have the functions both to adjust the "current-detecting-sensitivity" and to consist the low pass filter.




Fig. 31 Peripheral circuit diagram of CLM+ terminal




Fig. 32 Peripheral circuit diagram of CLM— terminal

To design the R_{NF1} and R_{NF2} , it is required to consider the influence of CLM terminal source current (I_{INCLM} or I_{INCLM}), which value is in the range of 90 to 270 μ A.

In order to be not influenced from these resistor paralleled value of R_{NF1} and $R_{NF2},\;(R_{NF1}//R_{NF2})$ is recommended to be less than $100\,\Omega.$

The R_{CLM} should be the non-inductive resistor.


(2)Over current limitting curve

(a)In case of feed forward system

Fig. 33 shows the primary and secondary current waveforms under the current limitting operation.

At the typical application of pulse by pulse primary current detecting circuit, the secondary current depends on the primary current. As the peak value of secondary current is limitted to specified value, the characteristics curve of output voltage versus output current become to the one as

shown in Fig. 34.



(b) Primary and secondary current

Fig. 33 Primary and secondary current waveforms under the current limitting operation condition on feed forward system




Fig. 34 Over current limitting curve on feed forward system

The demerit of the pulse by pulse current limitting system is that the output pulse width can not reduce to less than some value because of the delay time of low pass filter connected to the CLM terminal and propagation delay time T_{PDCLM} from CLM terminal to output terminal of type M51995. The typical T_{PDCLM} is 150ns.

As the frequency becomes higher, the delay time must be shorter. And as the secondary output voltage becomes higher, the dynamic range of on-duty must be wider, it means that it is required to make the on-duration much more narrower. So this system has the demerit at the higher oscillating frequency and higher output voltage applications.

To improve these points, the oscillating trackers is set

low using the characteristics of VF terminal. When the current limitting circuit operates under the over current condition, the oscillating frequincy decreases in accordance with the decrease of VF terminal voltage, if the VF is lower than 3.5V. And also the dead time becomes longer.

Under the condition of current limitting operation, the output current $\rm I_2$ continues as shown in Fig. 33. So the output voltage depends on the product of the input primary voltage $\rm V_{IN}$ and the on-duty.

If the third winding polarity is positive, the $V_{\rm CC}$ depends on $V_{\rm IN}$, so it is concluded that the smoothed voltage of $V_{\rm OUT}$ terminal depends on the output DC voltage of the SMPS.

So the sharp current limitting characteristics will be got, if the V_{OUT} voltage is feed back to VF terminal through low pass filter as shown in Fig. 35.




Fig. 35 Feed back loop through low pass filter from V_{OUT} to VF terminal

It is recommended to use 15k Ω for $R_{\text{VFFB}},$ and 10,000pF for C_{VFFB} in Fig.35.

Fig. 36 shows how to control the knee point where the frequency becomes decrease.




Fig. 36 How to control the knee point

(b)In case of fly back system

The DC output voltage of SMPS depends on the $V_{\rm CC}$ voltage of type M51995 when the polarity of the third winding is negative and the system is fly back. So the operation of type M51995 will stop when the $V_{\rm CC}$ becomes lower than "Operation-stop voltage" of M51995 when the DC output voltage of SMPS decreases under specified value at over load condition.




Fig. 37 Over current limitting curve on fly back system

However, the M51995 will non-operate and operate intermittently, as the V_{CC} voltage rises in accordance with the decrease of I_{CC} current.

The fly back system has the constant output power characteristics as shown in Fig. 37 when the peak primary current and the operating frequency are constant.

To control the increase of DC output current, the operating frequncy is decreased using the characteristics of VF terminal when the over current limitting function begins to operate.

The voltage which made by dividing the V_{CC} is applied to VF terminal as shown in Fig.38, as the induced third winding voltage depends on the DC output voltage of SMPS.

 $15k\Omega$ or less is recommended for R_2 in Fig. 38, it is noticed that the current flows through R_1 and R_2 will superpose on the $I_{\text{CC}(\text{START})}$ current.

If the R_1 is connected to C_{VCC2} in Fig. 27, the current flows through R_1 and R_2 is independent of the $I_{CC(START)}$.




Fig. 38 Circuit diagram to make knee point low on fly back system

(c)Application circuit to keep the non-operating condition when over load current condition will continue for specified duration

The CT terminal voltage will begin to rise and the capacitor connected to CT terminal will be charged-up, if the current limitting function starts and VF terminal voltage decreases below $V_{\text{THTIME}}(\simeq 3V)$.

If the charged-up CT terminal voltage is applied to OVP terminal through the level-shifter consisted of buffer transistor and resistor, it makes type M51995 keep negroup and condition.

M51995P.FP




Fig. 39 Application circuit diagram to keep the non-operating condition when over load current condition will continue for specified duration

Output circuit

(1)The output terminal characteristics at the V_{CC} voltage lower than the "Operation-stop" voltage




Fig. 40 Circuit diagram to prevent the MOS-FET gate potential rising

The output terminal has the current sink ability even though the V_{CC} voltage lower than the "Operation-stop" voltage or $V_{CC(STOP)}$ (It means that the terminal is "Output low state" and please refer characteristics of output low voltage versus sink current.)

This characteristics has the merit not to damage the MOS-FET at the stop of operation when the V_{CC} voltage decreases lower than the voltage of $V_{CC\,(STOP)}$, as the gate charge of MOS-FET, which shows the capacitive load characteristics to the output terminal, is drawn out rapidly.

The output terminal has the draw-out ability above the $V_{\rm CC}$ voltage of 2V, however, lower than the 2V, it loses the ability and the output terminal potential may rise due to the leakage current.

In this case, it is recommended to connect the resistor of 100k Ω between gate and source of MOS-FET as shown in Fig. 40.

(2)MOS-FET gate drive power dissipation


Fig. 41 shows the relation between the applied gate voltage and the stored gate charge.

In the region \bigcirc , the charge is mainly stored at C_{GS} as the depletion is spread and C_{GD} is small owing to the off-state of MOS-FET and the high drain votage.

In the region ②, the CGD is multiplied by the "mirror effect"

as the characteristics of MOS-FET transfers from off-state to on-state.

In the region $\ensuremath{\mathfrak{J}}$, both the C $_{GD}$ and C $_{GS}$ affect to the characteristics as the MOS-FET is on-state and the drain voltage is low



TOTAL STORED GATE CHARGE (nC)

Fig. 41 The relation between applied gate-source voltage and stored gate charge

The charging and discharging current caused by this gate charge makes the gate power dissipation. The relation between gate drive current I_D and total gate charge Q_{GSH} is shown by following equation;

Where

fosc is switching frequency

As the gate drive current may reach up to several tenths milliampere at 500kHz operation, depending on the size of MOS-FET, the power dissipation caused by the gate current can not be neglected.

In this case, following action will be considered to avoid heat up of type M51995.

- (1) To attach the heatsink to type M51995
- (2) To use the printed circuit board with the good thermal conductivity
- (3) To use the buffer circuit shown next section

(3)Output buffer circuit

It is recommended to use the output buffer circuit as shown in Fig. 42, when type M51995 drives the large capacitive load or bipolar transistor.



M51995P.FP

SWITCHING REGULATOR CONTROL




Fig. 42 Output buffer circuit diagram

DET

Fig. 43 shows how to use the DET circuit for the voltage detector and error amplifier.

For the phase shift compensation, it is recommended to connected the CR network between DET terminal and F/B terminal.




Fig. 43 How to use the DET circuit for the voltage detector

Fig. 44 shows the gain-frequency characteristics between point B and point C shown in Fig. 43.

The G_1 , ω_1 and ω_2 are given by following euqations;

$$G_{1} = \frac{R_{3}}{R_{1}//R_{2}}$$

$$\omega_{1} = \frac{1}{C_{2} \cdot R_{3}}$$

$$\omega_{2} = \frac{C_{1} + C_{2}}{C_{1} \cdot C_{2} \cdot R_{3}}$$
(13)

At the start of the operation, there happen to be no output pulse due to F/B terminal current through C1 and C2, as the potential of F/B terminal rises sharply just after the start of the operation.




Fig. 44 Gain-frequency characteristics between point B and C shown in Fig. 43

Not to tack the output pulse, is recommended to connect the capacitor C4 as shown by broken line.

Please take notice that the current flows through the R₁ and R_2 are superposed to $I_{\text{CC}\,(\text{START})}\,.$ Not to superpose, R_1 is connected to C_{VCC2} as shown in Fig. 27

How to get the narrow pulse width during the start of operation

Fig. 45 shows how to get the narrow pulse width during the start of the operation. If the pulse train of forcedly narrowed pulse-width continues too long, the misstart of operation may happen, so it is recommended to make the output pulse width narrow only for a few pulse at the start of operation. $0.1\mu F$ is recommended for the C.





Fig. 45 How to get the narrow pulse width during the start of operation

How to synchronize with external circuit

Type M51995 has no function to synchronize with external circuit, however, there is some application circuit for synchronization as shown in Fig. 46. If this circuit is used, the synchronization may be out of order at the overload condition when the current limitting function starts to operate and VF terminal voltage becomes lower than 3V.






Fig. 47 Driver circuit diagram (1) for bipolar transistor

Driver circuit for bipolar transistor

When the bipolar transistor is used instead of MOS-FET, the base current of bipolar transistor must be sinked by the negative base voltage source for the switching-off duration, in order to make the switching speed of bipolar transistor fast one.

In this case, over current can not be detected by detecting resistor in series to bipolar transistor, so it is recommended to use the CT(current transformer).

For the low current rating transistor, type M51995 can drive it directly as shown in Fig. 48.

Attention for heat generation

The maximum ambient temperature of type M51995 is + 85°C, however, the ambient temperature in vicinity of the IC is not uniform and varies place by place, as the amount of power dissipation is fearly large and the power dissipation is generated locally in the switching regulator.

So it is one of the good idea to check the IC package temperature. The temperature difference between IC junction and the surface of IC package is 15°C or less, when the IC junction temperature is measured by temperature dependency of forward voltage of pn junction, and IC package temperature is measured by "thermo-viewer", and also the IC is mounted on the "phenol-base" PC board in normal atmosphere.

So it is concluded that the maximum case temperature (surface temperature of IC) rating is 120°C with adequate margin.

As type M51995 has the modified totempole driver circuit, the transient through current is very small and the total power dissipation is decreased to the reasonable power level.

Fig. 49 shows the transient rush (through) current waveforms at the rising and falling edges of output pulse, respectively.






Fig. 48 Driver circuit diagram

(2) for small bipolar transistor



AT RISING EDGE OF



H-Axis: 20ns/div V-Axis: 10mA/div

AT FALLING EDGE OF OUTPUT PULSE

Fig. 49 Through current waveforms of totempole driver circuit at no-load and V_{cc} of 18V condition may be a supply of the condition of the co

APPLICATION EXAMPLE

Feed forward types SMPS with multi-output

