




15A (2C), 10A (4C) COMPACT POWER RELAYS WITH HIGH SENSITIVITY

SP-RELAYS



FEATURES

- High Vibration/Shock Resistance Vibration resistance: 18 G, amplitude 3 mm (10 to 55 Hz) Shock resistance: 40 G (11 ms)
- Latching types available
- High Sensitivity in Small Size 150 mW pick-up, 300 mW nominal operating power
- Wide Switching Range From 1 mA to 15 A (2C) and 10 A (4C)

SPECIFICATIONS

Contacts

Arrangeme	ent			2 Form C, 4 Form C				
Initial conta (By voltage			,	30 mΩ				
Initial conta	act press	ure		2C: Approx. 0.392 N (40 g 1.41 oz) 4C: Approx. 0.196 N (20 g 0.71 oz)				
Contact material				Stationary contact: Gold flashed silver alloy				
				Movable contact: Silver alloy				
Rating (resistive load)	Nominal switching capacity			2C: 15 A 250 V AC 10 A 30 V DC Data 4C: 10 A 250 V AC 10 A 30 V DC				
	Max. switching power			2C: 3,750 VA, 300 W 4C: 2,500 VA, 300 W				
	Max. sw	/itch	ning voltage	2C, 4C: 250 V AC, 30 V DC				
	Max. sw	/itch	ning current	2C: 15 A (AC) 10 A (DC), 4C: 10 A				
Expected life (min.	Mechanical (at 180 cpm)			5 × 10 ⁷				
	Electrical (at 20 cpm) (resistive load)	2C	15 A 250 V AC	10⁵				
			10 A 30 V DC	10⁵				
operations)		4C	10 A 250 V AC	10 ⁵				
			10 A 30 V DC	105				

Coil (polarized) at 20°C 68°F

Single side stable	Nominal operating power	300 mW
Latahina	Minimum set and reset power	150 mW
Latching	Nominal set and reset power	300 mW

Characteristics (at 25°C 77°F 50% Relative humidity)


Citalacteris	stics (at	23 6 77 1 30	70 Neiative Hulliuity)			
Max. operation	ng speed	(at rated load)	20 cpm			
Initial insulat	ion resista	ance*1	1,000 MΩ at 500 V DC			
Initial	Between	open contacts	1,500 Vrms			
breakdown	Betweer	contact sets	3,000 Vrms			
voltage*2	Between	contact and coil	3,000 Vrms			
Operate time	*3(at nom	ninal voltage)	Max. 30 ms (Approx. 25 ms)			
Release time (at nominal v		diode)*3	Max. 20 ms (Approx. 15 ms)			
Temperature rise (at nominal voltage)			Max. 40°C with nominal coil voltage and at nominal switching capacity			
Oh I '- I		Functional*4	Min. 392 m/s ² {40 G}			
Shock resista	ance	Destructive*5	Min. 980 m/s ² {100 G}			
Vibration resistance		Functional*6	176.4 m/s ² {18 G}, 10 to 55 Hz at double amplitude of 3 mm			
		Destructive	176.4 m/s ² {18 G}, 10 to 55 Hz at double amplitude of 3 mm			
Conditions for operation, transport and storage*7 (Not freezing and condens- ing at low temperature)		Ambient temp.	−50°C to +60°C −58°F to +140°F			
		Humidity	5 to 85% R.H.			
Unit weight			2C: 50 g 1.76 oz ; 4C: 65 g 2.29 oz			

Remarks

- Specifications will vary with foreign standards certification ratings.
- *1 Measurement at same location as "Initial breakdown voltage" section
- *2 Detection current: 10 mA
- *3 Excluding contact bounce time
- *4 Half-wave pulse of sine wave: 11ms; detection time: 10µs
- *5 Half-wave pulse of sine wave: 6ms
- *6 Detection time: 10μs
- *7 Refer to 5. Conditions for operation, transport and storage mentioned in AMBIENT ENVIRONMENT (Page 61).

ORDERING INFORMATION TYPICAL APPLICATIONS

NC machines, remote control panels, sophisticated business equipment.



(Notes) 1. PC board terminal types available as option. Please consult us for details.

- 2. 2 Form C: Carton: 20 pcs., Case: 200 pcs. 4 Form C: Carton: 10 pcs., Case: 100 pcs.
- 3. UL/CSA, TÜV approved type is standard.

www.DataSheet4U.com

DataShe

mm inch

DataShe

TYPES AND COIL DATA (at 20°C 68°F)

Single side stable

Part No. 2 Form C 4 Form C		Nominal voltage, V DC	Pick-up voltage, V DC (max.)	Drop-out voltage, V DC (min.)	Nominal operating current, mA	Coil resistance, Ω (±10%) 20°C	Inductance, H (at 120 Hz)	Nominal operating power, mW	Maximum allowable voltage, V DC (40°C)
SP2-DC3V	SP4-DC3V	3	2.1	0.3	100.0	30	Approx. 0.05	300	4.5
SP2-DC5V	SP4-DC5V	5	3.5	0.5	60.2	83	0.1	300	7.5
SP2-DC6V	SP4-DC6V	6	4.2	0.6	50.0	120	0.2	300	9
SP2-DC12V	SP4-DC12V	12	8.4	1.2	25.0	480	0.7	300	18
SP2-DC24V	SP4-DC24V	24	16.8	2.4	12.5	1,920	3.0	300	36
SP2-DC48V	SP4-DC48V	48	33.6	4.8	6.2	7,700	11.2	300	72

2-coil latching


Part No.		Nominal voltage,	voltage		Coil resistance, Ω (±10%)		Inductance, H (at 120 Hz)		Nominal operating	Maximum allowable
2 Form C	4 Form C	Voltage, V DC	voltage, V DC (max.)	current, mA	Coil I	Coil II	Coil I	Coil II	nower mil	voltage, V DC (40°C)
SP2-L2-DC3V	SP4-L2-DC3V	3	2.1	100.0	30	30	Approx. 0.03	Approx. 0.03	300	4.5
SP2-L2-DC5V	SP4-L2-DC5V	5	3.5	60.2	83	83	0.07	0.07	300	7.5
SP2-L2-DC6V	SP4-L2-DC6V	6	4.2	50.0	120	120	0.1	0.1	300	9
SP2-L2-DC12V	SP4-L2-DC12V	12	8.4	25.0	480	480	0.4	0.4	300	18
SP2-L2-DC24V	SP4-L2-DC24V	24	16.8	12.5	1,920	1,920	1.4	1.4	300	36
SP2-L2-DC48V	SP4-L2-DC48V	48	33.6	6.2	7,680	7,680	5.6	5.6	300	72

DIMENSIONS

2 Form C

et4U.com

Plug-in terminal



General tolerance: ±0.3 ±.012

Schematic (Bottom view) Single side stable



(Deenergized condition)


2 coil latching



(Reset condition)


Diagram shows the "reset" position when terminals 3 and 4 are energized. Energize terminals 1 and 2 to transfer contacts.

4 Form CPlug-in terminal




General tolerance: ±0.3 ±.012

Schematic (Bottom view) Single side stable



(Deenergized condition)

2 coil latching




(Reset condition)


Diagram shows the "reset" position when terminals 3 and 4 are energized. Energize terminals 1 and 2 to transfer to

SP


REFERENCE DATA

Operate and release time (Single side stable)







Coil temperature rise Sample: SP2-DC24V Ambient temperture: 20 to 22°C 68 to 72°F




Sample: SP4-DC24V Ambient temperature: 27 to 29°C 81 to 84°F




Electrical life (SP2, 15 A 250 V AC resistive load)






Electrical life (SP4, 10 A 250 V AC resistive load)



DataSheet4U.com



DataShe

www.DataSheet4U.com DataSheet4U.com


SP

ACCESSORIES mm inch

Soldering socket SP2-SS

35±0.6 1.378±0.02 7.5±0.3 295±.012 4.5±0.3 1.77±.012 4.5±0.3 1.496±.024 4.600±.016 4.800±.016


SP4-SS




Wrapping socket SP2-WS

et4U.com

52.8±0.6




SP4-WS



Mounting hole drilling diagram

52.8±0.6



Performance profile

· or or marries promo									
Item	SP2, socket SP4, socket SP2, wrap- with solder with solder ping socket		SP4, wrap- ping socket						
Withstand voltage	AC 3,000V, 1 min., between each terminal								
Insulation resistance	1,000 MΩ min								
Ambient working temperature	−50 to +60°C −58 to +140°F								
Maximum current, ON current	1 15 4 1 10 4		12 A	10 A					

Note: Do not remove the relay while it is ON.

Notes:

(1) Mounting screws and the fastening bracket are included in the package.

(2) Mount the relay with the proper mounting direction — i.e. with the direction of the DataSheet NAIS mark on top of the relay case match-

www.DataSheet4U.com

SP

Mounting and removal of fastening bracket


1. Mounting

Insert the A part of the fastening bracket into the mounting groove of the socket, and then fit the B part into groove, while pressing with the tip of a minus screwdriver.

2. Removal


Slide the B part of the fastening bracket

from the groove in the socket, while pressing with the tip of a minus screwdriver. While the bracket is in this position, keep pressing the C part of the bracket to the relay side with your finger, and lift up to the left side and remove from the groove, as in the diagram at right.









Mounting hole drilling diagram

30±0.2 1.181±.008 2-DIA. HOLES .177±.004

Notes:

(1) Mounting screws and the fastening bracket are included in the package.

(2) Mount the relay with the proper mounting direction — i.e. with the direction of the NAIS mark on top of the relay case matching the direction of the NAIS mark on the terminal block. (The 1) direction of the terminal block is the upward direction of the relay.)

Fastening bracket mounting and removal


1. Mounting

Insert the A part of the fastening bracket into the mounting groove of the terminal block, and then fit the B part into groove, while pressing with the tip of a minus screwdriver.


2. Removal

Slide the B part of the fastening bracket from the groove in the terminal block, while pressing with the tip of a minus screwdriver. While the bracket is in this position, keep pressing the C part of the bracket to the relay side with your finger, and lift up to the left side and remove from the groove, as in the diagram at right.






Mounting plate





The SP-Relay with SP-MA attached



Tolerance: ±0.1 ±.004



Direct chassis mounting possible, and applicable to DIN rail. [DIN 46277 (35 mm width) is applicable.]

www.DataSheet4U.com

Use method


- 1. Both the SP relay 2c and 4c can be mounted to the mounting slats.
- 2. Use the mounting slats either by attaching them directly to the chassis, or by mounting with a DIN rail.
- (A) When attaching directly to chassis Use two M3 screws.

For the mounting pitch, refer to the specification diagram.

(B) When mounting on a DIN rail Use a 35mm 1.378inch wide DIN rail (DIN46277).

The mounting method should be as indicated in the diagram at right.

Method for mounting on DIN rail



- (1) First fit the arc shaped claw of the mounting slat into the DIN rail.
- (2) Press on the side as shown in the diagram below.
- (3) Fit in the claw part on the opposite side.

Precautions for use

When mounting to a DIN rail, use a commercially available fastening bracket if there is a need to stop sliding of the mounting slat in the rail direction.

For Cautions for Use, see Relay Technical Information (Page 48 to 76).

et4U.com

DataSheet4U.com

www.DataSheet4U.com